3•2•1® *GS* SERIES III
3•2•1 SERIES III

DVD HOME ENTERTAINMENT SYSTEM

Owner's Guide

Guía de usario

Notice d'utilisation

Downloaded From TheatreSystem-Manual.com Manuals

SAFETY INFORMATION

Please read this owner's guide

Please take the time to follow this owner's guide carefully. It will help you set up and operate your system properly and enjoy all of its advanced features. Save this owner's guide for future reference.

WARNING: *To reduce the risk of fire or electric shock, do not expose the system to rain or moisture.*

WARNING: *Do not expose this apparatus to dripping or splashing, and do not place objects filled with liquids, such as vases, on or near the apparatus. As with any electronic product, use care not to spill liquids in any part of the system. Liquids can cause a failure and/or a fire hazard.*


CAUTION
RISK OF ELECTRICAL SHOCK
DO NOT OPEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK).
NO USER-SERVICABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED PERSONNEL.
AVIS
RISQUE DE CHOC ÉLECTRIQUE
NE PAS OUVRIR
ATTENTION : POUR RÉDUIRE LE RISQUE DE DÉCHARGE
ÉLECTRIQUE, NE RETIREZ PAS LE COUVERCLE (OU
L'ARRIÈRE). IL NE SE TROUVE À L'INTÉRIEUR AUCUNE
PIÈCE POUVANT ÊTRE RÉPARÉE PAR L'USAGER.
S'ADRESSER À UN RÉPARATEUR COMPÉTENT.

The CAUTION marks shown here are located on the bottom of your 3•2•1® home entertainment system media center and the rear panel of the Acoustimass® module:

The lightning flash with arrowhead symbol within an equilateral triangle alerts the user to the presence of uninsulated, dangerous voltage within the system enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

The exclamation point within an equilateral triangle alerts the user to the presence of important operating and maintenance instructions in this owner's guide.

CAUTION: *To prevent electric shock, match wide blade of plug to wide slot, insert fully.*

CAUTION: *Do not place any naked flame sources, such as lighted candles, on or near the apparatus.*

Class 1 laser product



This CD player is classified as a CLASS 1 LASER PRODUCT according to EN 60825-1:1994+A1+A2, IEC60825-1:1993+A1+A2.

CAUTION: *Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. The DVD player should not be adjusted or repaired by anyone except properly qualified service personnel.*

Class B emissions limits

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Batteries

Please dispose of used batteries properly, following any local regulations. Do not incinerate.

CE This product conforms to the EMC Directive 2004/108/EC and to the Low Voltage Directive 2006/95/EC. The complete Declaration of Conformity can be found at: www.Bose.com/static/compliance/index.html.

Additional safety information

See the additional instructions on the *Important Safety Information* sheet enclosed in the shipping carton.

Downloaded From TheatreSystem-Manual.com Manuals

CONTENTS

INTRODUCTION 2

Before you begin 2
For your records 3
Unpacking 4

SETUP 6

1 Placing the system components 6
2 Connecting the speakers to the module 8
3 Connecting the module to the media center 10
4 Connecting the system video to your TV 12
5 Connecting a cable box or other component . . . 17
To connect another component 19
To get digital audio from the component 20
To use video pass through 21
6 Connecting audio from your TV as an option 22
7 Installing the FM and AM radio antennas 25
8 Connecting the module to a power outlet 28
9 Setting the remote to control your TV and components 30
Inserting the remote batteries 30
Setting the remote for your TV 31
Controlling another component 32

FIRST-TIME USE 33

Trying out the DVD 33

CONTROLS AND INDICATORS 34

The remote control 34
Power and source buttons 35
Menu and movement buttons 36
Play and numeric buttons 37
Record and A, B, C buttons (not in Europe) 38
Colored buttons (in Europe only) 38
The media center 39
Display 39
Disc tray 39

OPERATION 40

Playing a video disc or CD 40
Selecting a play option 40
Keeping your discs clean 41
Checking for disc compatibility 42
For DVDs: Setting Parental Control 42
Choosing a password 42
Setting a restriction level 43
Ratings supplied by the MPAA 43

Downloaded From TheatreSystem-Manual.com Manuals

Playing a cable box or other component 44
Adjusting for audio delay 44
Getting digital audio from a source 45
Choosing other options 45
Listening to the radio 46
Creating a preset 46
Removing a station from a preset 46

ADJUSTMENTS TO THE PERFORMANCE 47

Changing system features 47
To get to the System menu 47
Selecting a new option 48
Language choices 48
Audio options 49
Video options 50
Media center options 52
Choosing new settings 53
To get to the Settings menu 53
Settings options 54

REFERENCE 59

Replacing remote batteries 59
Protecting the system 59
Cleaning the media center 59
Cleaning the speakers 59
Troubleshooting 60
For customer service 63
Limited warranty 63
Technical information 64

COPYRIGHT AND LICENSE PROTECTIONS 69

DEVICE CODES A-1

Downloaded From TheatreSystem-Manual.com Manuals

Downloaded From TheatreSystem-Manual.com Manuals

INTRODUCTION

Before you begin

Thank you for purchasing the 3•2•1® DVD home entertainment system. Using Bose® proprietary signal processing technology, the 3•2•1 system provides improved spaciousness from stereo recordings and bold movie effects for surround-sound sources.

System features include:

- Small, easy-to-place shelf speakers
- Easy-to-hide Acoustimass® module
- Integrated DVD/CD player and AM/FM tuner
- Remote and media center controls
- HDMI video connection to your TV
- Audio In connectors for three components
- Your choice of language for text displays

Downloaded From TheatreSystem-Manual.com Manuals

For your records

As you unpack the system, look for the serial numbers on the rear of the Acoustimass® module and the bottom of the media center.



This is a good time to record the serial numbers on the lines below and on your product registration card. You may need them if you ever contact Bose® Customer Service.

Acoustimass module serial number:

_____

Media center serial number:

_____

Dealer name:

_____

Dealer phone:

_____

Purchase date:

_____

We suggest you keep your sales receipt and the warranty information (on the product registration card) together with this owner's guide.

Downloaded From TheatreSystem-Manual.com Manuals

Unpacking

Carefully unpack your system. Save all packing materials, which provide the safest way to transport your system. Make sure your system includes the parts shown.

WARNING: *To avoid danger of suffocation, keep the plastic bags out of the reach of children.*

As you identify them, you may want to place a check mark in the box next to the name of each part.

If any part of the system appears damaged, do not try to use it. Notify Bose or your authorized Bose® dealer right away. For contact information, refer to the address sheet included in the carton.



❑ 3•2•1® GS speakers



❑ Media center



❑ 3•2•1 speakers



❑ Acoustimass® module

Downloaded From TheatreSystem-Manual.com Manuals



❑ Remote control and batteries

❑ Rubber feet for Acoustimass® module

❑ Rubber feet for speakers



❑ Setup disc



❑ Speaker cable



❑ Acoustimass module cable



❑ Acoustimass module power cord

❑ Stereo audio cable

❑ HDMI video cable



❑ Composite video cable



❑ AM antenna and stand

❑ FM antenna

Downloaded From TheatreSystem-Manual.com Manuals

SETUP

1 Placing the system components

What you need to use:



Media center



Speakers

OR



Speakers



Acoustimass® module

The image below shows one of the many ways you can position your new 3•2•1® system.



See Steps 1-6 for details.

Downloaded From TheatreSystem-Manual.com Manuals

1. On the bottom of each speaker, attach one set of small rubber feet.



2. Place the left and right speakers:
   - at least 3 feet (1 meter) apart
   - within 3 feet (1 meter) of the TV screen
   - near the front edge of any shelf
   - aimed straight ahead (not angled) to face the listening area

3. On the legs of the Acoustimass® module, attach the large rubber feet.



4. Place the Acoustimass module:
   - at the same end of the room as the speakers and your TV
   - at least 3 feet (1 meter) from the TV to prevent interference with the screen
   - several feet (.8 meters) from audio or video tapes to prevent magnetic damage to them
   - standing upright, not lying on a side, the front, or the back
   - with the front port aimed out from or along a wall for balanced performance
   - hidden under a table, behind a sofa or chair, or behind drapes as preferred
   - NOT in an enclosure, on a bed, on a sofa, or on a surface that can block the ventilation openings.

CAUTION: *Do not block ventilation openings on the bottom and rear of the module.*

5. Place the media center:
   - where nothing obstructs the front panel
   - near any components you will connect

6. Continue with 2 on the next page.

Downloaded From TheatreSystem-Manual.com Manuals

2 Connecting the speakers to the module

What you need to use:



Speaker cable



Speakers

OR



Speakers



Acoustimass® module

1. Notice the two plugs at one end of the speaker cable.



2. Separate the two plugs so each one reaches a speaker.



(Refer to 1 for placement guidelines.)

Downloaded From TheatreSystem-Manual.com Manuals

3. Insert each plug into the connector on the proper speaker.

The plug marked RIGHT goes into the speaker placed to the right of your TV.



4. Insert the remaining single plug into the connector labeled SPEAKERS on the back of the Acousti-mass® module.



5. Tighten each fastener screw by hand to secure the plug.

CAUTION: *Do not plug the Acoustimass module into an AC power (mains) outlet until all other components are connected.*

6. Continue with 3 on the next page.

Downloaded From TheatreSystem-Manual.com Manuals

3 Connecting the module to the media center

What you need to use:



Acoustimass® module cable

Media center

Acoustimass module

1. Notice the arrow on the top of the multi-pin plug at each end of the Acoustimass module cable.



2. Make sure you can see the arrow on top before you insert either end of the cable.

Downloaded From TheatreSystem-Manual.com Manuals

3. Insert this plug into the connector labeled ⊖ on the back of the Acoustimass® module.



Make sure the arrow on the plug faces up as you insert it.

4. On the other end of the cable, make sure you can see the arrow on top of the plug.

5. Insert this plug into the connector labeled Acoustimass Module on the back of the media center.



6. Continue with 4 on the next page.

Downloaded From TheatreSystem-Manual.com Manuals

4 Connecting the system video to your TV

What you may need to use:







This connection allows you to see DVDs and other video from the 3•2•1® system on your TV.

1. Select the HDMI video cable.

Downloaded From TheatreSystem-Manual.com Manuals

2. Check to see if your TV has an unused HDMI connector for VIDEO IN.

This may be located on the side or rear connector panel of the TV.



3. Follow the directions that are appropriate for your TV:

TV with HDMI on page 14

or

TV without HDMI on page 15

Downloaded From TheatreSystem-Manual.com Manuals

TV with HDMI

1. Insert one end of the HDMI cable into the HDMI connector on your TV.



Match the wide side of the plug to the wide side of the connector.

2. Insert the other end of this cable into the HDMI connector on the media center.

Make sure the Bose® logo shows as you insert the plug.



3. Continue with 5 on page 17.

Note: *If you make this HDMI connection, you do not need the supplied yellow Composite video cable to make any connections.*

DO NOT use either of the two ONLY PASS-THROUGH connectors on the back of the media center for video from a component.Neither S-Video nor Composite signals can pass through the HDMI cable to the TV.





Downloaded From TheatreSystem-Manual.com Manuals

TV without HDMI

1. Notice the yellow plug at each end of the Composite video cable.



Note: *There may be other kinds of video connectors on your TV that offer higher resolution than Composite. To use either S-Video or Component connectors, you need the appropriate cables. These cables are available at most electronics stores.*

2. Plug the Composite video cable into the yellow VIDEO IN connector on your TV.



Note: *If there is just one Composite Video In connector on your TV, it may be in use already for another video component. You can disconnect that component from the TV, and see "To use video pass through" on page 21.*

Downloaded From TheatreSystem-Manual.com Manuals

3. Insert the other end into the yellow Composite VIDEO OUT connector on the back of the media center.



.a

Note: *If you make this Composite connection, you can use the ONLY PASS-THROUGH connector on the media center for video from another component. See "To use video pass through" on page 21 for further information.*

4. Continue with 5 on the next page.

Downloaded From TheatreSystem-Manual.com Manuals

5 Connecting a cable box or other component

What you need to use:



Stereo audio cable



Media center



Your cable box, satellite box, or other component

You can listen to another sound source — like a cable or satellite box — through the 3•2•1® speakers instead of your TV.

This requires an audio connection only. Leave the video from your component connected to your TV.



5. Select the audio cable that has red and white plugs at each end.



Downloaded From TheatreSystem-Manual.com Manuals

6. Check to see if your cable or satellite box has red and white AUDIO OUT connectors.

A red and white audio cable may (**a**) or may not (**b**) already be attached to these connectors.

a.



OR

b.



c. If there are no AUDIO OUT connectors at all, continue with 6 on page 22.

3. To use the AUDIO OUT connectors, follow **a** or **b** as appropriate.

a. If an audio cable is already attached

Disconnect the cable from the TV only.



b. If an audio cable is not yet attached

Connect the cable to your cable or satellite box. Be sure to connect red to red and white to white.



Downloaded From TheatreSystem-Manual.com Manuals

4. Insert the plugs at the other end of the audio cable into the CBL•SAT AUDIO IN connectors on the media center.



To connect another component

In addition to your cable or satellite box, you can connect a second component, like a VCR. For this you need another audio cable with red and white plugs, available at most electronics stores.

1. Use this additional cable to connect to the AUDIO OUT on your component. Follow the method used in steps 1-3 on the previous pages.

2. Connect the other end of this cable to the AUDIO IN AUX on the 3•2•1® system media center.



Downloaded From TheatreSystem-Manual.com Manuals

To get digital audio from the component

For a component that is already connected to the media center, you can make a digital audio connection too.

For this higher quality audio, you need a digital audio cable that works with your component. Such cables are available at most electronics stores.

1. Identify the digital connector on your component as either an Optical or Coaxial connector.



2. Be sure to use the right cable for this connector.



Note: *If your component has an Optical and a Coaxial connector, use either one but not both.*

3. Connect one end of your digital cable to the digital AUDIO OUT connector on your component.

   Be sure to keep the red and white audio cable connected. This allows you to hear the audio if the program audio is not digital or the digital signal is interrupted.

4. Locate the appropriate digital AUDIO IN connector, labeled D, on the system media center.



You can make:

- up to 3 coaxial connections
- up to 2 coaxial and one optical connection

Note: *The media center Optical connector is factory set to work with a cable or satellite box. If your Optical component is neither of those, you need to select your component in an on-screen System menu. See "Getting digital audio from a source" on page 45.*

Downloaded From TheatreSystem-Manual.com Manuals

5. Plug the other end of your digital cable into the appropriate AUDIO IN connector on the media center.



The example here shows an Optical digital connection only.

To use video pass through

This calls for another composite cable or two S-Video cables, which are available at most electronics stores.

You can make a pass through connection if:

- You have a Composite or S-Video connection between the TV and the media center (not HDMI or Component).

AND:

- You want to connect another video component through the media center to the TV.

Be sure to use one matched pair as shown here:



DO NOT use either of the two ONLY PASS-THROUGH connectors (on the left) if you have made an HDMI or Component connection VIDEO OUT TO TV.

Continue with 6 on the next page.

Downloaded From TheatreSystem-Manual.com Manuals

6 Connecting audio from your TV as an option

What you need to use:

Audio cable



Media center



Your TV

For some setups, in order to hear your TV sound from your 3•2•1® speakers, you need to make this connection.

If:

- Your cable box does not provide red and white AUDIO OUT connectors.
- You watch TV programs without using a cable or satellite box.
- You connect a video camera or game console to your TV.

If none of the above apply, continue with 7 on page 25.

Note: *If you have already connected the audio cable provided with the system, you need another cable for this connection. These cables are available at most electronics stores.*

Downloaded From TheatreSystem-Manual.com Manuals

1. Insert the red and white plugs at one end of the cable into the AUDIO OUT connectors on the TV.



Be sure to match red to red and white to white.

Note: *In addition to this connection, you can make a digital AUDIO OUT connection from the TV to the media center. For more information, review "To get digital audio from the component" on page 20.*

Note: *If your TV does not provide AUDIO OUT connectors, you cannot connect the TV audio to the 3•2•1® system. Continue to use your TV speakers for TV program audio.*

The audio from other components that are connected to the 3•2•1 media center will play through the 3•2•1 speakers.

Downloaded From TheatreSystem-Manual.com Manuals

2. Insert the red and white plugs at the other end of this cable into the AUDIO IN TV connectors on the media center.



Be sure to match red to red and white to white.

3. Use your TV remote control to turn the TV speakers down to minimum volume.



This prevents the echo effect of audio playing through both the TV speakers and your 3•2•1® system speakers.

Downloaded From TheatreSystem-Manual.com Manuals

7 Installing the FM and AM radio antennas

What you need to use:

FM antenna



AM antenna and stand



Media center

For radio reception of broadcast radio programs, you need to use the supplied antennas.

For FM:

1. Select the FM antenna.



2. Insert the antenna plug into the FM antenna connector.



Downloaded From TheatreSystem-Manual.com Manuals

3. Straighten the antenna cable and spread the two ends far apart.

You may need to raise the ends and adjust the position to get clear reception.

For AM:

1. Select the AM antenna and stand.



Downloaded From TheatreSystem-Manual.com Manuals

2. Insert the antenna plug into the AM antenna connector.



3. Press firmly to attach the antenna loop to the provided stand.

   Small tabs on the antenna ring fit into notches on the stand.

4. Place the antenna in an upright position and at lease 20 inches (50 centimeters) from both the media center and the Acoustimass® module.

5. Continue with 8 on the next page.

Downloaded From TheatreSystem-Manual.com Manuals

8 Connecting the module to a power outlet

What you need to use:



Acoustimass® module power cable



Acoustimass module

1. Notice the large plug at one end of the Acoustimass module power cable.



Downloaded From TheatreSystem-Manual.com Manuals

2. Insert this plug into the power connector that is marked ~ on the Acoustimass® module.



Note: *On some systems, the Acoustimass module includes one of two controls.*

On 220-240V models only*, turn the POWER switch to on (* ***I*** *).*

On dual-voltage systems only*, set the voltage switch for the power that is appropriate to the region where you use the system.*

3. Plug the other cable end into the AC (mains) power.



CAUTION: *Bose recommends using a safety agency-approved surge protector on all electronic equipment. Voltage variations and spikes can damage electronic components in any system.*

Note: *Surge protectors are available at most electronics stores.*

4. Continue with 9 on the next page.

Downloaded From TheatreSystem-Manual.com Manuals

9 Setting the remote to control your TV and components

What you need to use:



Remote control and batteries



Your component



Your TV

When the batteries are installed, you can set the 3•2•1® remote to control your TV and other components connected to the media center.

Inserting the remote batteries

The two supplied AA batteries go into the compartment on the back of the remote control.

1. Slide the battery compartment cover off.



Symbols inside the compartment show how to match the – and + symbols on the batteries.

2. Insert the two batteries, making sure to match the markings.



3. Slide the cover back until it clicks into place.

Downloaded From TheatreSystem-Manual.com Manuals

Setting the remote for your TV

To use the 3•2•1® remote with your TV, you must set the remote for the proper TV device code.

1. Refer to the list of “Device codes” on page A-1.
2. In the list for TVs, find the brand of your TV.
3. Write down several codes for your brand so you can try more than one, if needed.

Note: *If one code works to turn your TV on and off but does not change channels, you can try other codes to find one that provides more complete TV control.*

4. Turn on the TV and your 3•2•1 system.
5. On the 3•2•1 remote, press and hold the TV button for several seconds.

   Wait until the red light at the top of the remote turns on.

6. Use the number buttons on this remote to enter the device code for your TV.



   The light turns off briefly as you press each key.

7. Make sure the light turns off completely after all digits are entered.

   If the light blinks now, the code is invalid. Return to step 5 and try a different code for your TV.

8. Point the 3•2•1 remote at your TV and press the TV On/Off button.



   Use the 3•2•1 remote to turn the TV on again and change channels, using the number buttons or by pressing Channel up or down.

   If it performs both operations, this code is correct. Write the code numbers below:

   If this code does not work, repeat steps 5-8 using a different code for your TV.

Note: *For a CD changer or combination CD/DVD player and changer, your brand may not be listed in the CD/DVD device codes on page A-21. In some cases, the same brand of DVD or VCR device codes can work with a changer.*

Downloaded From TheatreSystem-Manual.com Manuals

Controlling another component

With your CBL•SAT, VCR, or other component turned on, follow these steps.

1. In the Device Codes list, find the codes for the type and brand of your component.

2. On the 3•2•1® remote, press and hold the button for this component for several seconds.

   Wait until the red light at the top of the remote turns on.

3. Enter the device code for your component.

   The light turns off briefly as you press each key.

4. Make sure the light turns off completely after all digits are entered.

   If the light blinks instead of turning off, the code is invalid. Return to step 2 and try a different code for your component.

5. Point the 3•2•1 remote at your component and press the On/Off button for this source.



   Use the 3•2•1 remote to turn the component on again and to skip forward by pressing channel up or down.

   If it performs both operations, this code is correct. Write the code numbers below:

   If this code does not work, repeat steps 2-5 using a different code for your component.

Downloaded From TheatreSystem-Manual.com Manuals

Trying out the DVD

When you first turn on the system, you can play the provided DVD to get a step-by-step review of your setup.

1. Before you continue, make sure that:

- All of the cables needed for your setup are connected.
- Batteries are installed in the 3•2•1® system remote control.
- The system power cord is plugged in at both ends.

2. Turn on your TV.

- Use the TV On/Off button on the 3•2•1 remote if you have it set up to control your TV.
- Or use the remote control that came with the TV.



3. Play the provided DVD.

a. Point the 3•2•1 remote control at the media center and press CD/DVD.

b. On the media center controls, press Eject.

c. Insert the disc into the disc tray.

d. Press Eject again to close the tray and begin automatic play.



e. If the DVD does not begin playing, press the play button on the remote.

Playing the DVD helps verify that your system setup is correct.

Note: *If you do not see the DVD video on your TV screen, change the Video Input on the TV.*

Use the TV Input button on the 3•2•1 remote if you have it set up to control your TV.



Or use the button for Video Input on your TV remote control. For more information, refer to the owner's manual that came with your TV.

If you STILL do not see the DVD image on your screen, see the problem identified as "Sound, but no picture" under Troubleshooting on page 62.

Downloaded From TheatreSystem-Manual.com Manuals

The remote control

Aim the *3•2•1*® remote control at the media center or at the component you are controlling with the remote.

1. Press the white On/Off button near the top of the remote control.

   The system turns on to the last used source*, which may be:

   - CD•DVD
   - FM•AM
   - TV
   - CBL•SAT
   - AUX

   If your media center does not respond to the remote:

   - Make sure there is nothing blocking the front display where signals are received.
   - Aim more directly at the media center.
   - Move closer to the system.
     The control range of the remote is roughly 20 feet (6.2 meters).

**If your 3•2•1 system is connected by Bose® link cable to a Lifestyle® system in another room, your Lifestyle® system could be the selected source.*

2. Get to know how the remote works:
   - See the brief descriptions on pages 35-38.
   - Try out the various buttons to see how they work.

Downloaded From TheatreSystem-Manual.com Manuals

Power and source buttons

Turns the 3•2•1® system on and off.

Play begins with the source last used.

Silences or restores the sound.

Selects the built-in CD/DVD player as source and turns on the system.

Selects the built-in FM/AM radio as source and turns on the system to the station last used.

Switches between FM and AM when the radio is playing.



Selects audio from the TV source and turns your 3•2•1 system on if it was off.

If the remote is set up control your TV:

- Input selects a TV Video Input.
- On/Off turns the TV on and off.

Your remote also provides one of the two buttons shown here:

- For adjusting the on-screen aspect ratio of video from cable, satellite, or TV (but not DVD).

- For displaying teletext information that is provided with broadcast programs (in Europe only).

Selects the audio from the device connected to CBL•SAT on the media center rear panel.

Turns your 3•2•1 system on if it was off.

If the remote is set up to control this source, On/Off turns the cable or satellite box on and off.

Selects the audio from the device connected to AUX on the media center rear panel.

Turns your 3•2•1 system on if it was off.

If the remote is set up to control this source, On/Off turns the AUX device on and off.

Downloaded From TheatreSystem-Manual.com Manuals

Menu and movement buttons

Enters the Settings menu for the source that is playing.

Enters the System main menu.

Displays the DVD menu for the current disc on your TV screen.

Displays an on-screen program guide for any connected video devices that provide a guide.

Exits the 3•2•1® Settings or System menu.

Exits the on-screen menus or information screens of other connected video sources.

Moves ahead or back by one page in an electronic program guide, if one is available.

Confirms the selection of a menu item.



Moves up, down, left, or right in a menu or screen.



Tunes the FM/AM radio up or down to the next frequency.

Selects the next or previous item in a menu list.

Raises or lowers the volume.

- Pressing + raises the volume and unmutes the system (if muted).
- Pressing – lowers the volume.

Skips backward or forward to the next:

- TV, cable, or satellite channel
- CD track
- DVD chapter

Downloaded From TheatreSystem-Manual.com Manuals

Play and numeric buttons

Halts play of recorded music or video.

Pauses or resumes paused play of recorded music or video.

Starts or resumes play of recorded music or video.

Seek

For CD or MP3: Moves to the previous or next track.

- Press and hold scans through a track.

For DVD and DVR: Moves backward or forward in video.

- More presses increase the speed.

For FM/AM: Moves to the previous or next strong radio station.

Shuffle

For CD: Randomly plays the music.

- Pressing again ends random play.

For DVR: Moves backwards a few seconds with each press.

Repeat

For CD or MP3: Repeats the current track.

- Pressing again repeats the disc.
- Pressing three times ends the repeat.

For DVR: Moves forward a few seconds with each press.

1 2 3
4 5 6
7 8 9
0

For CD: Selects a track.

For DVD: Selects a chapter.

For TV, cable, or satellite: Selects the channel of the numbers pressed.

For FM/AM: Selects a preset radio station.

Info

For CBL•SAT: Displays or dismisses an on-screen information window (if one is available).

For MP3: Holding down the button displays or dismisses artist and title information on the media center display panel.

Previous

For TV, cable, or satellite: Returns to the channel last selected.

Downloaded From TheatreSystem-Manual.com Manuals

Record and A, B, C buttons (not in Europe)

These buttons can be used with a DVR, VCR, a cable box, or satellite box. This requires that the 3•2•1® remote is set to control the component.

Starts DVR or VCR recording of the cable, satellite, or TV program that is playing.

Makes a selection from a cable on-screen List A.

Makes a selection from a cable on-screen List B.

Makes a selection from a cable on-screen List C.

Colored buttons (in Europe only)

These buttons can be used with Teletext, a cable box, or a satellite box (if the 3•2•1 remote is set to control the box).

Red – Selects the screen content labeled red.

Green – Selects the screen content labeled green.

Yellow – Selects the screen content labeled yellow.

Blue – Selects the screen content labeled blue.

Downloaded From TheatreSystem-Manual.com Manuals

The media center

The front of the media center features:

Control buttons



On•Off	Turns the system power on or off.
Source	Displays and sets the choice of play options.
– Volume +	Lowers or raises the volume level.
Enter	Selects the next available radio preset.
Eject	Opens or closes the disc tray.

Note: *When you use the Source button on the media center to select a connected component for play, your 3•2•1® remote will not control that component. Press the CBL•SAT or AUX button on the remote to control that source.*

Display



When the system is turned on, the display shows:

- selected source (CD/DVD, for example)
- source status (stopped, for example)
- source data (elapsed DVD time, for example)
- system status (like disc tray OPEN, shown below)

Disc tray

Use the Eject button to open and close this tray. Do NOT push the tray to close it.



Downloaded From TheatreSystem-Manual.com Manuals

OPERATION

Playing a video disc or CD

1. Press CD•DVD on the 3•2•1® remote.

   This turns on the 3•2•1 system and selects the CD/DVD source.

   For video play, also turn on the TV.

   You may need to change the TV Video Input to see the correct video.

Note: *To prevent mid-play video disc problems, be sure the disc is clean. This is particularly important with rented DVDs.*

2. On the media center control panel, press Eject to open the disc tray.
3. Place the disc (right side up) in the tray.
4. Press Eject again to close the tray.

   The disc begins to play automatically.

   If not, press Play on the 3•2•1 remote.

The media center display registers disc information and progress as the play continues.

Note: *If the display text is not in your language, see "Language choices" on page 48.*

Note: *There are several ways to select a TV Video Input:*



- *If your 3•2•1 remote is set to work with your TV, press the TV Input button.*
- *If the remote is not set to work with your TV, use the Input button on your TV remote control. Or see your TV owner's guide for instructions.*

Selecting a play option

If you want to:

Interrupt play, press Pause on the remote control.

- To resume playing a paused disc, press Pause again. Or press Play.

Halt play, press Stop.

- To resume playing a stopped disc, press Play.
- To restart the disc at the beginning, press Stop once more and then press Play.

Skip to the next CD track or DVD chapter, press Chapter up.

Skip to the previous CD track or DVD chapter, press Chapter down.

Downloaded From TheatreSystem-Manual.com Manuals

Replay part of the disc, press Repeat.

- Press once to replay the CD track or DVD chapter.
- Press twice to replay a CD disc or DVD title.
- Press three times to end the replay.

Scan backward or **forward** through the disc, press and hold Seek reverse or Seek ahead.

Press Play to end the scan.

Stop a disc **and open** the disc tray, press Eject on the media center.

Keeping your discs clean

Scratches or dirt on a disc can prevent it from playing properly.

To avoid this problem:

- Handle discs by their edges to prevent fingerprints and scratches. Return them to their cases after use.
- Avoid exposing discs to:
  - chemical products that can cause damage.
  - writing directly on the disc or on a label attached to the disc.
  - direct sunlight, high temperatures, and humidity
- Use a soft, dry and lint-free cloth to clean the disc. Wipe straight out from the center to the edge.



Do not use a circular motion

Downloaded From TheatreSystem-Manual.com Manuals

Checking for disc compatibility

If you have trouble playing a disc, check to be sure it is one of the compatible types below.

- Video DVD
- Video CD
- DVD-R, DVD-RW
- Audio CD
- CD-R
- SACDs (CD-compatible content only)
- MP3 CDs:
  - — burned in a single closed session
  - — in disc format ISO9660
  - — with .mp3 as the extension and no other periods in the file name.

Region codes

For any DVD player and DVD disc to work together, the code for the region where they were sold must match. A code symbol is marked clearly on the bottom of your system media center and on the DVD cover (where it may be very small). For example, Region 1 is .

Copy protection

Music and other content may be protected by international and domestic copyright laws and may contain specific restrictions on use and/or reproduction. Please respect the rights of the artists and other copyright holders.

For DVDs: Setting Parental Control

You can password protect some DVDs that are not appropriate for other family members.

Choosing a password

1. Turn on your TV and your 3•2•1® system.

   Be sure to select the same TV Video Input that you use to watch a DVD.

2. Press the System button on your 3•2•1 remote control.

   The System menu appears on screen.

3. Press the right arrow button to select the DVD Lock icon .

4. Press ENTER.

5. Use the number buttons to create your four-digit password.

Downloaded From TheatreSystem-Manual.com Manuals

Setting a restriction level

1. Choose a Parental Control Setting from the chart of ratings defined by the Motion Picture Association of America (MPAA).

Ratings supplied by the MPAA

Parental Control Setting	MPAA Rating	Audience Restriction
8		None
7	NC-17	Adult audiences
6	R	Mature audiences
5		Mature teenage audiences
4	PG-13	Teenage audiences
3	PG	Mature young audiences
2		Most audiences
1	G	General

The numbers above the one you select will be restricted.

2. In the System menu, select DVD Lock and enter your password.
3. Use the arrow buttons to reach Lock UnRated Discs and select Yes.
4. Move down to Lock Discs Rated Above and right to the numbers.
5. Press the up or down arrow button to select a number.

   Any numbers above this selection will be restricted by password protection.
6. Press ENTER to save this setting and Exit to move out of the System menu.

Downloaded From TheatreSystem-Manual.com Manuals

Playing a cable box or other component

1. Press the button for the source (CBL•SAT or AUX) you want to play.

   This turns on the 3•2•1® system to the selected source.



2. Turn on your component and, if it is a video source, turn on the TV.

   If the 3•2•1 remote is set to control the component, you can press the source On/Off button on the remote.



3. Choose the proper Video Input on your TV if the source is a video component.

Adjusting for audio delay

While playing a DVD, you may notice that the picture and audio are not in perfect sync. For example, you see a person's lips move after you hear the words.

To make small adjustments to this timing, use the audio delay setting on the 3•2•1 system:

1. Press the Settings button on the 3•2•1 remote control.

   The Settings menu appears on screen.

2. Move down to the audio delay icon and press ENTER.

3. Select an adjustment (1-8) and wait to see if this corrects the problem.

   Each selection makes a minute timing adjustment. It may be difficult to notice the change.

Downloaded From TheatreSystem-Manual.com Manuals

Getting digital audio from a source

For an Optical digital audio connection to the media center, the connected component must be recognized by the system.

Currently, the system is set to recognize CBL•SAT as the Optical component.

If the Optical connection is for a different component:

1. Display the 3•2•1® system menu on the TV by pressing System.
2. Move right to the Media Center icon and press ENTER.
3. Move down to Optical Source and press ENTER.
4. Move up or down to select a component from the list and press ENTER.
5. Press Exit to leave the System menu.

Note: *When using your 3•2•1 system with the TV, turn the volume on your TV set all the way down. This prevents an echo effect from two sets of speakers playing.*

Choosing other options

The 3•2•1 system provides optional settings and adjustments to meet your specific needs.

For example you can:

- Set a countdown time for the system to turn off automatically.
- Choose another language for text on the media center display and in system menus.
- Adjust the bass or treble audio compensation.
- Change the image format on your TV screen.

Note: *Your TV may provide an on-screen menu to make changes to the video image.*

For a full list and description of these options, see “Adjustments to the performance” on page 47.

Downloaded From TheatreSystem-Manual.com Manuals

Listening to the radio

Your 3•2•1® system includes an FM and AM radio.

1. On the 3•2•1 remote, press FM•AM.

   This turns on the 3•2•1 system and plays the radio station last selected.

2. Press the FM•AM button to switch between FM and AM.

3. Press the Channel up or down buttons to tune from one station to another.

To tune to:

- A preset station, press the Preset number button.
- The next clear station, press a Seek button.

Creating a preset

You can assign a preset number for 20 FM and 20 AM stations. Then, by pressing the preset number, you tune immediately to the particular station:

1. Tune to the station you want to assign to a preset.
2. Choose the number you want to assign to that station.
3. Press and hold the chosen number button:
   - For numbers 1 through 9, press and hold the button.

     PRESET:x* SET appears briefly on the media center display.
   - For numbers 10 through 20, press the first number, then press and hold the second number.

     PRESET:xx* SET appears briefly on the display.

Removing a station from a preset

1. Press the number of the preset.
2. Listen to be sure this is the preset you want to erase.
3. Press and hold zero.

   PRESET:xx* ERASED appears briefly on the display.

**x represents the number you select.*

Downloaded From TheatreSystem-Manual.com Manuals

Changing system features

If your system operates as you want it to, you may not need any changes.

Some kinds of setup, however, require a change for optimal performance. In most cases, you make a System change just once.

The features that you can change include:

- Audio
- Video
- Media Center
- DVD Lock

Using the DVD Lock feature is described in “Playing a video disc or CD” on page 40.

For details on the other options available, refer to the tables on the pages that follow.

To get to the System menu

The System menu appears on your TV screen only.

1. Turn on your 3•2•1® system.
2. Turn on your TV and select the TV Video Input that you use to watch a DVD.
3. Press the System button on your 3•2•1 remote.

   The System menu appears on your TV screen.
4. To get into the menu, move right and select an icon (like Media Center, shown on page 48) for one of the system features.

   The list of options appears on the menu screen.

Note: *Entering the System menu pauses a DVD or CD.*

Downloaded From TheatreSystem-Manual.com Manuals



Selecting a new option

1. Make sure you see the System menu on your TV screen.
2. Move right to select the system feature you want to change and press ENTER.
3. Press the up and down buttons to move to the option you want.

   As explanation for each options appears at the bottom of the menu when you highlight the option by moving up or down.
4. Press ENTER to select the option.
5. Change the option by selecting a new setting (or by pressing number buttons, as needed).
6. Press Exit to leave the System menu.

Language choices

You can select the language you prefer to see on-screen and on the media center display. To make this change, move to the Display Language option in the Media Center feature of the System menu.

Downloaded From TheatreSystem-Manual.com Manuals

Audio options

These options affect the way the system sounds in your home.

Option	Default Setting (Options)	Description
Bass Compensation	0 (–14 to +14)	Zero is for standard low-tone performance. – decreases and + increases these low tones.
Treble Compensation	0 (–14 to +14)	Zero is for standard high-tone performance. – decreases and + increases these high tones.
Audio Processing	Automatic (User Adjustable)	Keeps Bose® processing as the standard. Allows some processing options (Movie EQ, Range Compression, Mono Decoding) to appear in Settings menus.
Input Levels: TV Analog Input Level TV Digital Input Level CBL•SAT Analog Input Level CBL•SAT Digital Input Level AUX Analog Input Level AUX Digital Input Level	Normal (–6, –3, +3, +6)	Decreases or increases the volume level setting for the input of a connected component. This minimizes abrupt volume changes when you switch from DVD or FM•AM audio on the Bose media center to audio from a connected component. ***Note:*** *To match AM and FM levels, which can vary depending on the program or station, adjusting the volume on your audio component may be preferable.*
DVD Audio (*Only for TVs connected to the media center by HDMI cable.)*	Bose 3•2•1 (TV Stereo)	Plays the DVD audio from 3•2•1® media center over the 3•2•1 speakers. Sends two channels of DVD audio by HDMI cable to the TV and plays this sound on the TV speakers as well as on the Bose® speakers.

Downloaded From TheatreSystem-Manual.com Manuals

Video options

These options affect the way the picture looks on your TV.

Option	Default Setting (Options)	Description
Widescreen TV ***Note:*** *If your TV is connected using an HDMI cable, you may not see a choice of settings.*	Yes (16:9) (No 4:3)	Yes tells the system that widescreen (16:9) is the TV format. No tells the system that 4:3 is the TV format. For a TV connected using a Composite, S-Video, or Component cable, selecting No also makes available the DVD Image option (below). ***Note:*** *If you are not sure what type of cable is used to connect your TV, check the Video Connector indicator, which is explained on page 51.*
DVD Image ***Note:*** *This option is NOT available UNLESS you have selected No in the Widescreen TV option (above) for your TV connected using a Composite, S-Video, or Component cable (not HDMI).*	Modified (Original)	For a TV connected using an HDMI cable: Modified allows the Bose® system to automatically provide the resolution that is preferred for your TV (usually 720 or 1080), so the image fills the screen. You can change this video resolution in the Settings menu. Original tells the Bose® system to keep the image in the original DVD format (in 480 or 576 resolution), regardless of how it fills the screen. No change can be made to this video resolution in the Settings menu. (Some TVs determine automatically how to fill the screen, overriding any choice.) For a TV connected using non-HDMI cable: Modified allows the Bose system to adjust the images on some widescreen DVDs to fill a 4:3 TV screen. This is done by removing the black bars on top and bottom and by cropping the sides of the image. (Many DVD images, even widescreen, will still appear with black bars on top and bottom.) Original tells the Bose system to keep the image in the original format of the DVD. A widescreen DVD image will have black bars on top and bottom.

Downloaded From TheatreSystem-Manual.com Manuals

Option	Default Setting (Options)	Description
Video Connector *(Only an indicator.)*	(HDMI) (Composite + S-Video) (Component)	Identifies the type of video connection made on the back panel of the media center. This is not an adjustable setting.
Video Black Level *(Appears on screen only if the TV connects to the media center using a Composite or S-Video cable.)*	Normal (Extended)	Screen black level generally appropriate for most TVs. Darkens the intensity of the black on screen.
TV Video Format	NTSC - US (PAL - EUROPE) (MULTISTANDARD)	Correct for NTSC (U.S. standard) monitors. Correct for PAL (European standard) monitors. Only for a TV that supports multiple formats (NTSC and PAL).
Progressive Scan (*Appears on screen only if the TV connects to the media center using a Component cable. It is not needed with HDMI.)*	Off (On) ***Note:*** *If selecting On distorts your screen, press the remote up arrow to reselect Off.*	Screen image repaints in standard style. Screen image repaints in advanced style (if your TV provides this option). ***Note:*** *With an HDMI connection, you will not see the On option. The HDMI cable automatically senses your TV capabilities and applies progressive scan as appropriate.*

Downloaded From TheatreSystem-Manual.com Manuals

Media center options

These options affect general operation of the system.

Option	Default Setting (Options)	Description
Display Brightness	4 (1 to 4)	Media center display shows text at its brightest. Choosing a lower number darkens text on the display.
Display Language	English (Dansk, Deutsch, Español, Français, Italiano, Nederlands, Svenska)	On-screen display menus appear in the selected language.
Optical Source	CBL•SAT (TV, AUX)	Set for a component connected by Optical cable to the CBL•SAT AUDIO IN on the 3•2•1® media center. Identifies a different component connected by Optical cable to the media center.
Tuner Spacing	US (European)	Applies the regional standard for incremental spacing between AM and FM stations.
Bose Link Room Code	B (C, D, E, F, G, H, I, J, K, L, M, N, or O)	Links the 3•2•1 system to a unique code so it works with Bose® link as a second room sound source. Bose link expansion is a Lifestyle® system feature.
Restore Settings	No (Yes)	Maintains your established changes in the Settings menu. Returns all of your selections in the Settings menu to the original factory settings.

Downloaded From TheatreSystem-Manual.com Manuals

Choosing new settings

You can use the 3•2•1® Settings menus for quick adjustments while you watch a video or listen to music.

For example, if you want to change the screen resolution for DVDs, you will find that option in the TV Settings menu.

To see these options, enter the Settings menu for the selected source. Symbols and definitions for the options that are offered appear on screen.

Note: *Some of the settings made while you are playing a particular source are temporary. When you change sources or turn off the system, these settings revert to the factory selections.*

To get to the Settings menu

1. Use the 3•2•1 remote to select the audio or video source that you want to change.
2. Press the Settings button.

   The Settings menu that affects this source appears on your media center display.

   It also appears on screen if your TV is on and you select the proper TV Video Input.
3. Move up or down to the option you want and press ENTER.
4. Move right to select a new setting for that option and press ENTER.
5. Press Exit to leave the Settings menu.

The Settings menu appears as a vertical bar of icons. To familiarize yourself with the icons, see “Settings options” on pages 54-59.

Downloaded From TheatreSystem-Manual.com Manuals

Settings options

	Features	Default Setting (Options)	Effect
	Audio Delay *Available only for DVDs and connected video components.*	0 (0, 1, 2, 3, 4, 5, 6, 7, 8)	Each number change adjusts the delay by about 30 milliseconds. The most noticeable mismatch in the video and audio synchronization (caused by the video processing in some TVs), occurs in scenes with people talking. If they appear to finish sentences before their lips stop moving, select a different Audio Delay setting to correct this condition.
	Movie EQ *Available only if Audio Processing is set to Adjustable in the Audio System menu.* *(Not available for CD or FM·AM.)*	Off (On)	Leaves the equalization of the movie soundtrack as originally recorded. Adjusts the equalization of the movie soundtrack to better suit some home theater installations. ***Note:*** *To turn on Movie EQ, the Audio Processing option in the System menu must be set as User Adjustable.*
	Range Compression *Available only if Audio Processing is set to Adjustable in the Audio System menu.* *(Not available for CD or FM·AM.)*	Off (On)	Leaves the volume range of the movie soundtrack as originally recorded. Reduces the volume range of sounds on a movie soundtrack. Late at night or at other quiet times, the startling difference between the quietest and loudest audio passages in a movie can be a problem. Turning this feature On moderates those effects. ***Note:*** *To turn on Range Compression, the Audio Processing option in the System menu must be set as User Adjustable.*

Downloaded From TheatreSystem-Manual.com Manuals

	Features	Default Setting (Options)	Effect
	Mono Decoding *Available only if Audio Processing is set to Adjustable in the Audio System menu.* *(Not available on CD or FM·AM.)*	Off (On)	When one-channel (mono) is the audio input, this mono signal is sent to both speakers. Processes the signal from one-channel (mono) audio input (if it is detected) for right and left channel output.
	Audio 1 + 1 *Available only if a dual mono signal is detected on a video CD or digital broadcast.*	1 (2, Both)	Allows you to decode and play bilingual audio from a VCD or single-channel digital broadcast. When the digital audio content is on two channels, each channel carries a unique mono soundtrack (1 + 1). Changing this setting allows you to hear the audio on mono channel 2, or both mono channels at the same time.
	Video Resolution *Adjustable only for a TV connected by HDMI AND only if the DVD Image setting in the System menu is Modified.*	_____* Default (1080p, 1080i, 720p, 480/576p, 480/576i)	Your 3•2•1® system sets its DVD video resolution to match the default that is communicated to it by the TV. You can experiment with other settings to see which one provides the best picture. HDTVs can accept different resolutions as input, and in some cases the highest number does not result in the best picture. ***Important note:*** *When you change resolution, your TV screen takes several seconds to make the transition. Allow for this adjustment before pressing other buttons.*

Downloaded From TheatreSystem-Manual.com Manuals

ADJUSTMENTS TO THE PERFORMANCE

	Features	Default Setting (Options)	Effect
	Time *(For DVD only.)*	_:_ _ (0:00)	Changing the elapsed time moves to a different point in the DVD.
	Title *(For DVD only.)*	__ of __	Changing the first number moves to a different title on the current disc. Some DVDs do not allow direct access to titles.
	Chapter *(For DVD only.)*	__	Changing this number moves to a different chapter on the current disc. Some DVDs do not allow direct access to chapters.
	Audio Track *(For DVD only.)*	Dependent on disc	Gives you a choice of audio tracks on the current disc.
	Subtitle Language *(For DVD only.)*	Dependent on disc	Gives you a choice of subtitle languages (if several are included on the disc).
	Camera Angle *(For DVD only.)*	1 of __	Gives you a choice of camera angles (if several are included on the disc).

Downloaded From TheatreSystem-Manual.com Manuals

	Features	Default Setting (Options)	Effect
	A-B Repeat *(For DVD only.)*	A, B	Repeats a segment of the DVD after the start and end points are defined. To begin: **1.** Move backward or forward to the point in the DVD where you want the segment to start. **2.** Press ENTER. **3.** Move to the point where you want it to end. **4.** Press ENTER. Repeats until you select this setting option again and press ENTER.
	Track *(For CD only.)*	__ of __	Changing this first number moves to a different track on the current disc.

Downloaded From TheatreSystem-Manual.com Manuals

ADJUSTMENTS TO THE PERFORMANCE

	Features	Default Setting (Options)	Effect
	Sleep Timer	Off (10-90)	Setting countdown minutes causes your 3•2•1® system to turn off when the time reaches 0. The choices, from 10 to 90 minutes, are divided into 10-minute increments. To cancel the timer, select Off.
	Output Mode *(For FM only.)*	Auto (Mono-Stereo)	Allows you to choose stereo or monaural (mono) audio performance by selecting: • Auto – The FM tuner will automatically play in stereo if that is available. Otherwise, it will play in mono (single channel). • Mono – The FM tuner will always play in mono. • Stereo – The FM tuner will always play in stereo if available. Otherwise, it plays mono. When you change the tuner frequency, the setting resets to Auto.
	RDS Info *(For FM and only on some systems.)*	On (Off)	Displays any station and program information that is available from the Radio Data System.

Downloaded From TheatreSystem-Manual.com Manuals

Replacing remote batteries

Replace both batteries when the remote control stops operating or its range seems reduced. Alkaline batteries are recommended.

1. Slide open the battery compartment cover on the back of the remote.
2. Remove both batteries.

   Be sure to dispose of the batteries according to the regulations in your area.
3. Insert two AA (IEC-R6) 1.5V batteries, or the equivalent. Match the + and – symbols on the batteries with the + and – markings inside the compartment.
4. Slide the battery compartment cover back into place.



Protecting the system

Follow the guidelines below for keeping the system in good working order.

- Do not allow liquids to spill into any openings.
- Do not use any solvents, chemicals, or cleaning solutions containing alcohol, ammonia, or abrasives.
- Do not use any sprays near the system.

Cleaning the media center

Use only a soft, dry cloth to clean the outside surfaces of the media center.

Cleaning the speakers

Use a soft, damp cloth. Or use an ammonia-free window cleaner on a soft cloth to maintain the finish.

Downloaded From TheatreSystem-Manual.com Manuals

Troubleshooting

System issues	What to do
System doesn't turn on	• Make sure the Acoustimass® module power cord is inserted securely into the AC (mains) power outlet and into the power connector on the Acoustimass module. • Be sure to press a source button (CD•DVD, CBL•SAT, etc.) on the 3•2•1® remote. • Unplug the power cord for 60 seconds, then plug it in again. This allows the unit to reset itself after a power surge or power interruption. • For a 230-240V system (used typically in Europe), make sure the power switch on the Acoustimass module is turned on (**I**). • For a dual voltage 3•2•1 system only, make sure the voltage setting is correct for your region. If it is set to 115V, the system may not operate in a 230V region. ***CAUTION:*** *Do not change the voltage switch from 230V to 115V unless you are certain it is appropriate for the power supply in your location.*
No sound	• Increase the volume. • Check to see if MUTE is lit on the display. If it is, press the Mute button on the remote control to unmute the sound. • Be sure that you have pressed the correct source button (CD•DVD, CBL•SAT, etc.) on the 3•2•1 remote. • Check the audio connections for the component you want to play. • Connect the FM and AM antennas. • Make sure that the cable between the Acoustimass module and the media center is connected securely. • Check connections between the speakers and the Acoustimass module. • Turn off the media center for 60 seconds, then on again, to restore communication between the media center and the speakers.
Sound is distorted	• Make sure speaker cables are not damaged and the connections are secure. • Reduce the volume level on the external device playing through the 3•2•1 system speakers.
Sound is marred by a loud hum or buzz	• Try plugging your system into a different AC outlet. • Check to see if your media center and its audio input cable are within 3 ft (1 m) of any other electronic or electrical device. Some examples are a TV, cable box, VCR, wireless internet router, dimmer switches, blinking lights, or microwaves. • Move the media center farther away and notice if the humming still occurs.

Downloaded From TheatreSystem-Manual.com Manuals

System issues	What to do
No sound from TV only	• If your TV has Variable instead of Fixed audio output, you need to turn off the TV speakers internally. Refer to your TV owner's guide and follow the instructions provided there.
Speech and lip movement on screen are not in sync	• Adjust the Audio Delay using the Settings menu on screen. For details, refer to "Choosing new settings" on page 53.
Radio does not work or has poor reception	• Make sure the antennas are connected and positioned as shown in "Installing the FM and AM radio antennas" on page 25. • Adjust the FM antenna position to reduce interference. • Move antennas farther from the media center, TV, or other electronic equipment. • Select another station. You may be in an area of weak signal coverage for some stations.
Volume level changes when another sound source is selected	• Change the Audio Level for the source input so its volume matches the volume of the radio and DVD in the Bose® system. Refer to "Audio options" on page 49.
Remote issues	**What to do**
3•2•1® remote does not control your TV, CBL•SAT, or AUX component	• Make sure that the remote is set to control the component. Refer to "Setting the remote for your TV" on page 31. • Make sure that the front of the component is not obstructed. • Reset the remote using a different device code for the component you want to control. Refer to "Device codes" located at the back of the book. There may be several codes that can turn the component on and off, but only one that provides further control (channel changing, for example).
3•2•1 remote behaves erratically or does not work	• Aim the remote at the front of the media center. • Make sure the battery polarity (+ and –) matches the polarity marked in the battery compartment. • Install new batteries. Refer to "Replacing remote batteries" on page 59.

Downloaded From TheatreSystem-Manual.com Manuals

Video issues	What to do
Sound, but no picture	• Make sure the TV is on. • Make sure the TV is set to the correct Video Input to see the video from DVDs on the Bose® system. • Make sure a DVD is in the disc tray. • If the TV is connected to the media center using the HDMI cable: – Switch from one Video Input to another and then back to the original input. – Turn everything off, then: A. Turn on the TV and set the TV Video Input for the Bose system video. B. Turn on the 3•2•1® system and press DVD. – Turn off both the TV and the 3•2•1 system and then: A. Unplug the HDMI cable from both ends. B. Disconnect the power cables from both your TV and the 3•2•1 Acoustimass® module. C. Re-connect power to the television and to the Acoustimass module. D. When the 3•2•1 startup message disappears from the display, re-connect the HDMI cable. E. Turn on the TV first, then turn on the 3•2•1 system. – Disconnect the HDMI cable that connects the TV to the 3•2•1 media center. Reconnect the two using a Component cable, an S-Video cable, or the Composite cable provided with the system.
Incorrect picture for the selected source	• Make sure the TV is set to the correct Video Input.
Picture is black and white, flickers, gets dark, or rolls	• Check the video cable connections. • If the media center is connected to the TV using a Component cable, make sure the colored cable plugs (red, green, and blue) match the connector colors on the media center and on the TV. • Check the Video Format setting (NTSC or PAL) and change it. Refer to “Video options” on page 50.
Picture is not clear or is unstable	• Use the Settings menu to lower the output resolution of the system. Your 3•2•1 system sets its DVD video resolution to match the default that is communicated to it by the TV. You can experiment with other settings to see which one provides the best picture. HDTVs can accept different resolutions as input, and in some cases the highest number does not result in the best picture.

Downloaded From TheatreSystem-Manual.com Manuals

Disc issues	What to do
DVD or CD does not play ***Note:*** *If you are using the HDMI cable between the TV and media center, there are other possible solutions in "Sound, but no picture" on the previous page.*	• Make sure the Acoustimass® module power cord is inserted securely into the AC (mains) power outlet and into the power connector on the Acoustimass module. • Check to see if the Play symbol in the display is lit. • After pressing the CD•DVD button, wait a few seconds and press Play**.** • Make sure the disc is properly inserted (label-side up). • Eject the disc and try loading it again. • Clean the disc to remove fingerprints, dust, or dirt. Refer to "Keeping your discs clean" on page 41. • Try another disc. Some discs are defective and will not play. • Make sure the disc is compatible with the media center disc player. Also make sure the region codes match. Refer to "Checking for disc compatibility" on page 42.
Disc won't eject	• Follow these steps: 1. Turn off the unit. 2. Unplug the Acoustimass module power cord from the outlet for 60 seconds, then reconnect it. This allows the unit to reset itself. 3. Before powering on, press and hold Eject on the media center.
Lock DVD password lost	• Enter the password 2673 to gain entry to the Lock DVD screen.

For customer service

For additional help in solving problems, contact Bose® Customer Service. Refer to the address sheet included in the carton.

Limited warranty

This system is covered by a transferable limited warranty. Details of the limited warranty are provided on the *Product Registration Card* that came with your system.

Downloaded From TheatreSystem-Manual.com Manuals

Technical information

Power rating

USA/Canada: 120V~ 60Hz 300W
International: 220-240V~ 50/60Hz 300W
Dual voltage: 115/230V~ 50/60Hz 300W

Antennas

FM 75Ω – external FM antenna
AM – external AM antenna

Maximum ambient temperature

104°F (40°C)

Dimensions

Media center: 3¼"H x 13¾"W x 10"D
(8.3 cm x 34.9 cm x 25.4 cm)

Remote control: 1⅛"H x 2½"W x 9"D
(3.0 cm x 6.5 cm x 22.9 cm)

Speakers: 2½"H x 5½"W x 4"D
(6.4 cm x 14 cm x 10.5 cm)

Acoustimass® module: 14½"H x 8¾"W x 19⅛"D
(36.7 cm x 22.2 cm x 48.5 cm)

Weights

Media center: 6.7 lb (3.0 kg)
Speakers: 1 lb (.45 kg) each
Acoustimass module: 23.3 lb (10.6 kg)

Finish

Media center: polymer
Speakers: polymer
Acoustimass module: polymer

Downloaded From TheatreSystem-Manual.com Manuals

GLOSSARY

4:3 – See “Aspect ratio.”

16:9 – See “Aspect ratio.”

A

Analog audio – The sounds that we hear with our ears, unlike digital audio that is encoded as bits of information.

Aspect ratio – An expression for the width of the picture relative to the height. For example, if the aspect ratio is 4:3 (considered a normal screen), the shape of that picture is 4 units wide by 3 units high. The standard TV aspect ratios are 4:3 and 16:9 (called widescreen).



C

CD – The abbreviation for a compact disc that stores digitally encoded music that is read by the laser beam in a compact disc player. This provides high-quality playback.

Chapter – A main division of contents in a DVD title.

Coaxial cable – Can carry digital audio signals between a source device and the 3•2•1® system.

Component video – Also called YPbPr for its three-part video signals that include luminance and two color signals. Component video requires the use of a Component cable. This provides considerably better resolution than is possible from either Composite or S-Video signals.

Composite video – The simplest of video signals, which combines black and white with color information. Its low- resolution signal is compatible with the broadest range of televisions and other video components and requires a simple RCA video cable.

Downloaded From TheatreSystem-Manual.com Manuals

D

Digital audio – Audio in digital form, which is encoded as bits of information.

Dolby Digital – A means of encoding multi-channel audio, developed by Dolby Laboratories and accepted as an international standard.

– The logo representing Dolby Digital.

DTS – An abbreviation for Digital Theater Systems. DTS encoding provides a type of multi-channel surround sound format used on certain CDs and many DVDs.

– The logo representing DTS.

DVD – An abbreviation most commonly known to mean digital video disc or digital versatile disc. A DVD looks like a CD but contains high-quality video and multi-channel audio for movies.

DVD-R, DVD-RW – Abbreviations for Recordable (R) and ReWriteable (RW) Digital Video (or Versatile) Disc (DVD). Data can be added to a DVD-R once only, and to a DVD-RW more than once.

DVD-ROM – The abbreviation for Read Only Memory (ROM) on a Digital Video (or Versatile) Disc (DVD), which allows no data to be added.

DVD video – A standard for storing and reproducing audio and video on DVD-ROM discs, based on MPEG video, Dolby Digital audio, and other proprietary data formats.

DVR – An abbreviation for Digital Video Recording (otherwise known as PVR for Personal Video Recording). With a hard drive, an electronic program guide, and internal processing, a DVR simplifies recording and playback of programs.

Downloaded From TheatreSystem-Manual.com Manuals

H **HDCP** – An abbreviation for High-bandwidth Digital Content Protection. HDCP is a form of Digital Rights Management licensed by Digital Content Protection, LLC, to control digital audio and video content as it travels across Digital Visual Interface (DVI) or High-Definition Multimedia Interface (HDMI) connections. (It prevents unauthorized copying of programs.)

HDMI – An abbreviation for High-Definition Multimedia Interface. HDMI is a de-facto standard interface that delivers clear, all-digital audio and video via a single cable.

HDTV – An abbreviation for High-Definition TV, a digital television format that delivers sharper picture quality with more lines of resolution. HDTV offers a much better picture quality than standard television.

I **IR** – An abbreviation for infrared. Pertains to the type of remote that sends/receives commands on an infrared light beam.

L **Letterbox** – A video format that has an aspect ratio wider than 4:3 (refer to Aspect ratio) and is shown with black bars above and below the picture.

M **MP3** – This is a compressed audio format (MPEG-1 Layer III) that allows the recording of many hours of music on a single CD.

MPEG – An abbreviation for Moving Picture Experts Group, the committee of experts from the audio, video, and computer industries involved in setting standards for compression of moving images.

N **NTSC** – An abbreviation for National Television System Committee and the label for its video format standard used for televisions in the U.S. and other countries.

O **Optical cable** – Carries digital audio via optical fiber between a source device and your 3•2•1® system.

P **PAL** – An acronym for the Phase Alternate Line video format used extensively in Western Europe.

PCM – An abbreviation for Pulse Code Modulation. A common form of digital audio signal.

Progressive scan – A video format that displays all lines of the picture frame in a single pass and refreshes the TV image 30 times per second. Not compatible with all video displays.

PVR – Refer to DVR.

R **RDS** – A system that displays radio broadcast station and programming information. This feature is available on European systems only.

Resolution – The sharpness of a video image, signal, or display, generally described either in terms of lines of resolution or pixels.

Downloaded From TheatreSystem-Manual.com Manuals

S **SCART** – A type of connector commonly found on consumer electronics products manufactured for use in Western Europe.

Screen ratio – See Aspect ratio.

Source – Any device that provides audio or video signals for use with the 3•2•1® system. The AUDIO OUT from such a device connects to the AUDIO IN on the media center

S-Video – A video signal that separates the black and white from the color information. S-Video provides higher resolution than Composite video, but not as high as Component video. This type of connection requires use of an S-Video cable.

T **Teletext** – An information retrieval service provided by television broadcast companies in Europe and some other countries, not including the U.S.

Title – A main component of contents on a DVD. There can be several titles on a DVD, one of which may be a movie.

V **Video CD** – A compact disc (CD) that contains video.

W **Widescreen** – A TV having an aspect ratio of 16:9 with a picture shape that is 16 units wide by 9 units high. (Refer to Aspect ratio.)

Y **YPbPr** – See Component video.

Downloaded From TheatreSystem-Manual.com Manuals

©2008 Bose Corporation. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission.

The distinctive design of the 3•2•1® media center is also a registered trademark of Bose Corporation.

Manufactured under license from Dolby Laboratories. “Dolby” and the double-D symbol are trademarks of Dolby Laboratories. Confidential Unpublished Works. ©1992-1997 Dolby Laboratories. All rights reserved.

This product contains one or more programs protected under international and U.S. copyright laws as unpublished works. They are confidential and proprietary to Dolby Laboratories. Their reproduction or disclosure, in whole or in part, or the production of derivative works therefrom without the express permission of Dolby Laboratories is prohibited. ©1992-1996 by Dolby Laboratories, Inc. All rights reserved.

MPEG Layer-3 audio compression technology licensed by Fraunhofer IIS and THOMSON multimedia.

Manufactured under license under U.S. Patent #’s: 5,451,942; 5,956,674; 5,974,380; 5,978,762; 6,487,535 & other U.S. and worldwide patents issued & pending. DTS and DTS Digital Surround are registered trademarks and the DTS logos and Symbol are trademarks of DTS, Inc. ©1996-2007 DTS, Inc. All Rights Reserved.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

Consumers should note that not all high definition television sets are fully compatible with this product and may cause artifacts to be displayed in the picture. In case of 525 or 625 progressive scan picture problems, it is recommended that the user switch the connection to the “standard definition” output. If there are questions regarding your TV set compatibility with this model 525p and 625p DVD player, please contact our customer service center.

Designed with UEI Technology™ Under License from Universal Electronics Inc. ©UEI 2000-2002.

This product incorporates copyright protected technology and other intellectual property rights owned by Cirrus Logic, Inc. and subject to the copyright protection of the U.S. as well as other licensing restrictions and protections. Use of this copyright protected technology is limited solely to use with the Cirrus Logic integrated circuits incorporated in this product. Reverse engineering or disassembly is prohibited.

The Simplay™ logo and the ‘Simplay™,’ and ‘Simplay Labs™,’ trademarks are owned by Silicon Images, Inc. and are used under license from Silicon Images, Inc. and/or Simplay Labs, LLC.

HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing, LLC.

Downloaded From TheatreSystem-Manual.com Manuals

DEVICE CODES

TV **A-2**

CBL **A-15**
Cable box

SAT **A-16**
Satellite receiver

CD/DVD **A-21**

DVD **A-21**

VCR **A-26**

A-ACC **A-32**
Audio accessory

V-ACC **A-32**
Video accessory

R-ACC **A-32**
Audio receiver

Downloaded From TheatreSystem-Manual.com Manuals

TV

888	0264, 0412
A-Mark	0047, 0054, 0003, 0009, 0020, 0032, 0039, 0165
A.R. Systems	0556, 0037, 0455, 0352, 0374
Abex	0032
Accent	0037, 0009
Accuscan	0047, 0018, 0135
Acec	0012
Acer	1339
Acoustic Research	1269
Action	0030, 0650, 0003, 0019, 0052, 0185
Acura	0009
Addison	0653, 0108, 0092, 1150
ADL	1217
Admiral	0047, 0054, 0017, 0051, 0093, 0463, 0180, 0264, 0016, 0018, 0019, 0163, 0165, 0179, 0418
Advantz	0282
Advent	0761, 0783, 0815, 0817, 0842, 1933
Adventura	0046
Adventuri	0000
Adyson	0032, 0217
AEG	1163, 1556
Agashi	0264, 0217
Agna	0150
Aiko	0037, 0361, 0264, 0433, 0009, 0035, 0092, 0217, 0371
Aim	0706, 0037, 0455, 0753
Aiwa	0264, 0032, 0701, 1180, 1904, 1911, 1916
Akai	0000, 0060, 0812, 0702, 0178, 0030, 0145, 0556, 0037, 0548, 0714, 0606, 0361, 0264, 0218, 0433, 0696, 0729, 0745, 0753, 1935, 0826, 1259, 1537, 1675, 1676, 1903, 0672, 0648, 0602, 0480, 0473, 0412, 0371, 0217, 0208, 0163, 0151, 0056, 0038, 0035, 0009
Akashi	0009, 0860
Akiba	0037, 0218, 0455, 0282
Akira	0418
Akito	0037
Akura	0171, 0037, 0714, 0668, 1037, 0264, 0218, 0009, 0163, 0282, 0412, 1498, 1556, 1982
Alaron	0170, 0179
Alba	0037, 0714, 0668, 1037, 0487, 0370, 0218, 0036, 1935, 0474, 0443, 0418, 0371, 0163, 0038, 0032, 0009
Albatron	0700, 0843
Alfide	0672
All-Tel	0865, 1269
Alleron	0030, 0170
Allorgan	0217
Allstar	0037
Ambassador	0150, 0177
America Action	0180
American High	0000, 0060
Amplivision	0370, 0217
Ampro	0751
Amstrad	0000, 0171, 0037, 1037, 0264, 0218, 0433, 0163, 0039, 0177, 0033, 0011, 0362, 0371, 0412, 0648, 0009, 1982
Amtron	0000, 0180, 0019
Anam	0250, 0180, 0037, 0003, 0009, 0628, 0700
Anam National	0250, 0037, 0650, 0055
Andersson	1149, 1163
Anglo	0264, 0009
Anhua	0051
Anitech	0037, 0264, 0009, 0282, 0474
Ansonic	0037, 0668, 0370, 0009, 0012, 0163, 0374, 0411
AOC	0451, 0093, 0180, 0060, 0178, 0030, 0108, 1365, 1150, 1089, 0628, 0474, 0185, 0179, 0157, 0092, 0052, 0039, 0038, 0032, 0019, 0018, 0009, 0003
Aolinpike	0264, 0412
Apex Digital	0156, 0748, 0765, 0185, 0767, 0879, 0890, 1217, 1943
Apollo	0473
AR	0556, 0352
Arc En Ciel	0109
Arcam	0217
Archer	0003
Ardem	0037, 0714
Aristocrat	0163
Aristona	0556, 0037, 0012
ART	1037
Arthur Martin	0163
ASA	0070, 0105
Asberg	0037
Asora	0009
Astar	1531, 1548
Astra	0037
Asuka	0264, 0218, 0217, 0282
ATD	0698
Atlantic	0037
Atori	0009
Auchan	0163
Audinac	0180
Audio-Technica	0019
Audiosonic	0037, 0714, 0486, 0264, 0370, 0218, 0009, 0109, 0217, 0374, 0820, 1308
Audioton	0486, 0264, 0370, 0217
Audiovox	1564, 0451, 0180, 0003, 0092, 0179, 0623, 0802, 0875, 1937
Audioworld	0698
Aumark	0060
Autovox	0217, 0247, 0544
Aventura	0171
AVP	0000
Awa	0451, 0606, 0264, 0036, 0108, 0009, 0011, 0157, 0217, 0374, 1376
Axion	1937
Axxent	0009
Axxon	0714
Baihe	0264, 0009, 0412
Baile	0009, 0374, 0661

Downloaded From TheatreSystem-Manual.com Manuals

Baird	0037, 0109, 0179, 0208, 0217, 0343, 1196
Bang & Olufsen	0565, 0619, 1620
Baohuashi	0264, 0412
Baosheng	0009, 0817
Barco	0556, 0163
Basic Line	0556, 0037, 0668, 1037, 0218, 0455, 0009, 0163, 0217, 0282, 0339, 0374, 1163
Bastide	0217
Baur	0037, 0195, 0361, 0455, 0146, 0512, 0535, 0544, 0554
Baycrest	0032, 0046, 0186
Baysonic	0236, 0463, 0180
Bazin	0217
Beaumark	0017, 0178, 0030, 0019, 0179
Beijing	0812, 0264, 0226, 0009, 0208, 0374, 0412, 0661, 0817
Beko	0037, 0714, 0195, 1037, 0486, 0606, 0370, 0418, 0808
Belcor	0030, 0019
Bell & Howell	0054, 0017, 0154, 0093, 0016, 0179
Belson	0698
Belstar	1037
BenQ	1032, 1315, 1562, 1756
Beon	0037, 0218, 0032, 0039, 0163, 0418
Berthen	0668
Best	0370
Bestar	0037, 0370, 0374
Bestar-Daewoo	0374
Binatone	0217
Black Diamond	1909, 1037, 0614, 0753, 0820, 1163
Black Star	0247
Blackway	0218, 0282
Blaupunkt	0195, 0036, 0455, 0170, 0200, 0327, 0535, 0554
Blue Sky	0556, 0037, 0714, 0668, 1037, 0487, 0218, 0455, 0282, 0499, 1254, 1314, 1363, 1916
Blue Star	0282
Bondstec	0247
Boots	0009, 0217
Boxlight	0893
BPL	0037, 0208, 0282, 0896
Bradford	0180
Brandt	0625, 0714, 0560, 0109, 0287, 0335
Brick	0039
Brinkmann	0037, 0668, 0486, 0418, 0519
Brionvega	0037, 0362
Britannia	0217
Brockwood	0178, 0030, 0019, 0056
Broksonic	0236, 0463, 0180, 0003, 0039, 0177, 1911, 1929, 1935, 1938
Brother	0264
BSR	0163
BTC	0218
Bush	0556, 0037, 0714, 0668, 1037, 0698, 0487, 0361, 0264, 0218, 0036, 1259, 1556, 1900, 0661, 0660, 1954, 0614, 0519, 0374, 0371, 0355, 0335, 0282, 0217, 0208, 0163, 0009
Byd:sign	1309, 1311
C-Tech	0891, 0896
Caihong	0009, 0817
Cailing	0748
Caishi	0891
Candle	0030, 0039, 0046, 0056, 0186
Canton	0218
Capehart	0017, 0178, 0030, 0036, 0003, 0019, 0032, 0046, 00052, 0092
Capetronic	0030, 0003
Capsonic	0264
Carad	0668, 1037, 0610
Carena	0037, 0455
Carnivale	0030
Carrefour	0037, 0036, 0070
Carver	0054, 0170
Cascade	0037, 0009
Casio	0037
Cathay	0037, 0218, 0032, 0474
CCE	0037, 0217
Celebrity	0000
Celera	0765
Celestial	0767, 0820
Centrex	0706, 0780, 0826, 0891
Centrum	1037
Centurion	0037
Century	0247
CGE	0370, 0074, 0163, 0247, 0418
Changcheng	0051, 0264, 0009, 0374, 0412, 0661, 0817
Changfei	0009, 0374, 0817
Changfeng	0264, 0412, 0696, 0753, 0817
Changhai	0009, 0817
Changhong	0156, 0765, 0264, 0508, 0009, 0767, 0783, 0817, 0820, 1156
Chengdu	0009, 0817
Ching Tai	0003, 0009, 0092, 0179, 0474
Chun Yun	0000, 0180, 0003, 0009, 0033, 0092, 0179, 0474, 0700, 0843, 1150
Chunfeng	0264, 0009
Chung Hsin	0180, 0053, 0036, 0108, 0033, 0474, 1150
Chungfeng	0412
Chunsun	0009, 0817
Cimline	0218, 0009
Cinema	0672
Cineral	0451, 0092
Cinex	0648, 1556
Citek	0047, 0032
Citizen	0054, 0000, 0451, 0463, 0180, 0060, 0030, 0171, 1935, 1928, 0535, 0003, 0016, 0282, 0280, 0186, 0019, 0092, 0020, 0056, 0046, 0039, 0035, 0032
City	0009
Civet	0185
Clairtone	0185
Clarion	0180
Clarivox	0037, 0070, 0418
Classic	0030, 0019, 0056, 0092, 0499

Downloaded From TheatreSystem-Manual.com Manuals

Clatronic	0037, 0714, 0264, 0370, 0218, 0009, 0217, 0247, 0371
Clayton	1037
CMS Hightec	0217
Colortyme	0047, 0054, 0017, 0060, 0178, 0030, 0018, 0019, 0032
Colt	0019
Commercial Sols	0047, 1447
Concerto	0056
Concorde	0009
Condor	0037, 0264, 0370, 0009, 0247, 0282, 0411, 0418
Conia	0754, 0820, 1498
Conic	0178, 0032
Conrac	0808
Conrowa	0156, 0145, 0698, 0264, 0009, 0412, 0696, 0753, 1156
Contec	0180, 0037, 0036, 0009, 0157, 0185
Continental Ed.	0487, 0109, 0287
Cosmel	0037, 0009
Craig	0180, 0171, 0179, 0282
Crosley	0054, 0000, 0180, 0030, 0171, 0370, 0074, 0096, 00163, 0187, 0247
Crown	0093, 0180, 0053, 0037, 0714, 1037, 0486, 0487, 0606, 0712, 0370, 0412, 0418, 0339, 0208, 0672,0 0056, 0039, 0009
Crown Mustang	0672
CS Electronics	0218, 0247
CTC	0247
CTX	1756
Curtis Mathes	0047, 0054, 0154, 0000, 0051, 0451, 0093, 0180, 0060, 0702, 0178, 0030, 0145, 0166, 0037, 0179, 0466, 1147, 1347, 1919, 0056, 0044, 0039, 0038, 0035, 0032, 0019, 0018, 0016
CXC	0180
Cybertron	0218
Cytron	1326
Cytronix	1298
D-Vision	0556, 0037, 1982
Daenyx	0180, 0179, 0672
Daewoo	0154, 0451, 0180, 0178, 0030, 1661, 0556, 0037, 0634, 1909, 0264, 0218, 0036, 0108, 1928, 0661, 0672, 0700, 1902, 0860, 0865, 1756, 1755, 0880, 1150, 1307, 1598, 0003, 0009, 0019, 0020, 0032, 0039, 0056, 0092, 0109, 0170, 0217, 0374, 0474, 0499, 0623, 0627, 0628
Dainichi	0218
Dansai	0037, 0036, 0009, 0032, 0035, 0208, 0217
Dansette	0412
Dantax	0714, 0486, 0370
Datsura	0208
Dawa	0037, 0009
Daytek	0672, 1376
Dayton	0009, 0092
Daytron	0180, 0178, 0030, 0037, 0036, 0009, 0019, 0032, 0039, 0056, 0092, 0374
Dayu	0374, 0661
De Graaf	0548, 0044, 0163, 0208
DEC	0891
Decca	0037, 0033, 0217
Degraff	0163, 0208
Deitron	0374
Dell	1080, 1178, 1264
Delphi	0829
Delta	1369
Denko	0264
Denon	0145, 0038, 0055, 0511, 0576
Denstar	0628
Denver	0037, 0587, 1189
Desmet	0037, 0009
Dewo	0628
Diamant	0037
Diamond	0706, 0698, 0009, 0371, 0672, 0820, 0825, 0860, 0896
Dick Smith Elec.	0698, 1556
Digatron	0037
Digiline	0037, 0668, 0105
Digital Life	0780, 0872, 0891
Digitex	0820
Digitor	0037, 0698
Digix Media	0880
Dixi	0037, 0009, 0217, 0247
DL	0587, 0780, 0872, 0891
DMTech	1964
Domeos	0668
Domland	0394
Dongda	0009
Donghai	0009
Dream Vision	1704
Drean	0037
DSE	0698, 0820, 1556
DTS	0009
Dual	0037, 1037, 1137, 0217, 0343, 0352, 0394, 0519, 0544
Dual Tec	0217
Dumont	0017, 0180, 0178, 0016, 0019, 0032, 0070, 0217
Durabrand	0463, 0180, 0178, 0171, 0003, 1034, 1463
Dux	0037, 0012
DVX	0891
Dwin	0093, 0720, 0774
Dynatech	0217
Dynatron	0037, 0012
Easy Living	1248
Eaton	0060
Ecco	0773
ECE	0037
Edison-Minerva	0487
Elbe	0037, 0610, 0218, 0217, 0362, 0411
Elcit	0163, 0247
Electroband	0000, 0185
Electrograph	1755
Electrohome	0154, 0000, 0463, 0150, 0178, 0030, 0019, 0032, 0039, 0056, 0151, 0185, 0381
Elekta	0264, 0009, 0282
Elektra	0017, 1661
Element	1498
Elfunk	1037, 1208
ELG	0037

Downloaded From TheatreSystem-Manual.com Manuals

Elin	0037, 0548, 0361, 0009
Elite	0037, 0218
Elta	0264, 0009, 0474
Emco	0247
Emerald	0178, 0177
Emerson	0047, 0017, 0154, 0451, 0236, 0463, 0180, 0150, 0178, 0171, 0037, 0714, 0668, 0195, 1909, 0486, 0361, 0370, 0036, 0282, 0371, 0623, 1394, 1911, 1928, 1929, 0280, 0247, 0185, 0179, 0177, 0170, 0146, 0135, 0111, 0070, 0044, 0039, 0038, 0032, 0019, 0012
Emperor	0282
Envision	0030, 0019, 0032, 0039, 0813, 1365
Enzer	0753, 0860
Epson	0833, 0840, 1290, 1322, 1122
Erres	0037, 0012
ESA	0812, 0171
ESC	0037, 0217, 0474
Ether	0030, 0003, 0009
Etron	0009, 0163, 0820
Eurofeel	0264, 0217
Euroman	0037, 0264, 0370, 0217
Europa	0037
Europhon	0037, 0109, 0217
Evesham	1248
Evolution	1756
Expert	0163
Exquisit	0037, 0247
Feilang	0009
Feilu	0009, 0817
Feiyan	0264, 0412
Feiyue	0009, 0817
Fenner	0009, 0374
Fer0	0335
Ferguson	0053, 0037, 0625, 0548, 0560, 0195, 1037, 0003, 0109, 0287, 0335, 0343, 0443, 1935
Fidelity	0171, 0037, 0361, 0264, 0163, 0217, 0371, 0412, 0423, 0474, 0512, 0544
Filsai	0217
Finlandia	0548, 0361, 0105, 0163, 0208, 0346
Finlux	0556, 0037, 0714, 0070, 0105, 0163, 0179, 0217, 0346, 0411, 0473, 0480, 0492, 0808, 1556
Firstar	0236, 0009, 0033
Firstline	0556, 0037, 0714, 0668, 1037, 0361, 0009, 0208, 0217, 0247, 0374, 0411, 0544, 0808, 1363
Fisher	0047, 0054, 0154, 0000, 0361, 0370, 0036, 0157, 0159, 0208, 0217, 0544
Flint	0037, 0610, 0264, 0218, 0455
Force	1149
Formenti	0037, 0163
Fortress	0093
Fraba	0037, 0370
Friac	0037, 0610, 0370, 0009, 0499
Frontech	0264, 0009, 0163, 0217, 0247, 0474
Fujimaro	0865, 1498
Fujitsu	0009, 0179, 0186, 0217, 0352, 0683, 0809, 0853, 1181
Fujitsu General	0009, 0186, 0217, 0683
Fujitsu Siemens	0808, 0809, 1163, 1298
Funai	0000, 0180, 0171, 0668, 0264, 0039, 0179, 0342, 1271, 1904
Furi	0145, 0264, 0412, 0817
Furichi	0860
Futronic	0264, 0860
Futuretech	0180
Galaxi	0037
Galaxis	0037, 0370
Ganxin	0817
Gateway	1755, 1756
GBC	0218, 0009, 0163, 0374
GE	0047, 0000, 0051, 0451, 0093, 0180, 0060, 0178, 0030, 1447, 1454, 0625, 0560, 1922, 1919, 1917, 11347, 1147, 0018, 0335, 0282, 0135, 0021, 0092, 0055, 0052, 0027, 0046, 0044, 0038, 0035
GEC	0037, 0361, 0163, 0217
Geloso	0009, 0163, 0247, 0374
Gemini	0047
General	0109, 0186, 0287
General Elec.	0047, 0021, 0027, 0055
General Tech.	0009
Genesis	0037, 0009
Genexxa	0037, 0218, 0009, 0163, 0412
Gericom	0808, 0865, 0880, 1217, 1298
Giant	0009, 0217
Gibralter	0017, 0000, 0030, 0019
Gintai	0474, 1150
Go Video	0060, 0886
Go Vision	1937
Goldfunk	0668
GoldStar	0047, 0054, 0154, 0178, 0030, 0037, 0714, 0606, 0361, 0036, 0455, 0247, 0474, 1150, 1154, 1378, 1926, 0217, 0163, 0109, 0056, 0044, 0039, 0032, 0019, 0018, 0009
Gooding	0487
Goodmans	1163, 0000, 0556, 0037, 0625, 0714, 0560, 0668, 0634, 1909, 1037, 0487, 0264, 0218, 0036, 0587, 0009, 1900, 1376, 1308, 1259, 0335, 0880, 0808, 0011, 0032, 0661, 0035, 0343, 0179, 0217, 0499, 0360, 0480, 0374, 0371
Gorenje	0370
GPM	0218
GPX	0179
Gradiente	0053, 0037, 0056, 0170
Graetz	0714, 0487, 0361, 0163, 0339, 0371, 1163

Downloaded From TheatreSystem-Manual.com Manuals

Gran Prix	0179, 0648
Granada	0037, 0548, 0560, 0036, 0108, 0226, 0012, 0032, 0146, 0163, 0208, 0217, 0339, 0343, 0473
Grandin	0037, 0714, 0668, 1037, 0610, 0218, 0455, 0009, 0163, 0282, 0374, 0865, 0880
Gronic	0217
Grundig	0706, 0556, 0037, 0195, 0487, 0036, 0587, 1954, 1935, 1916, 1376, 1308, 0683, 0672, 0554, 0535, 0443, 0163, 0070, 0009
Grundy	0180, 0195, 0179
Grunkel	1163
Grunpy	0180, 0179
H & B	0808
Haaz	0706
Haier	0037, 0698, 0587, 0508, 0768, 0891, 0896, 1034
Haihong	0009
Haiyan	0264, 0412, 0817
Halifax	0264, 0217
Hallmark	0236, 0180, 0178, 0019, 0135, 0179, 0187
Hampton	0217
Hanimex	0218
Hankook	0180, 0178, 0030, 0019, 0056, 0628
Hannspree	1348, 1351
Hanseatic	0556, 0037, 0714, 0634, 0361, 0370, 0009, 0217, 0282, 0394, 0499, 0519, 0544, 0661, 0808
Hantarex	0037, 0009, 0829, 0865
Hantor	0037
Harley Davidson	0000, 0180, 0060, 0178, 0030, 0019, 0179, 1904
Harman/Kardon	0054
Harsper	0865
Harvard	0180
Harwa	0773, 1196, 1269
Harwood	0037, 0487, 0009, 0032, 0412
Hauppauge	0037
Havermy	0093
HCM	0037, 0264, 0218, 0009, 0217, 0282, 0412, 0418
Heathkit	0017
Helios	0865
Hello Kitty	0451
Hema	0009, 0217
Hemmermann	0544
Hewlett Pkd	1494, 1502, 1088, 1089, 1642
Hicon	1467
Hifivox	0109
Highline	0037, 0264
Hikona	0218, 0474
Hikone	0218
Himitsu	0180, 0628
Hinari	0037, 0264, 0218, 0036, 0009, 0032, 0096, 0163, 0179, 0208, 0282, 0352, 0355, 0443
Hisawa	0714, 0610, 0218, 0455, 0282
Hisense	1363, 0156, 0748, 0145, 0556, 0508, 0009, 0208, 0696, 0753, 0780, 0860, 1156, 1208, 1314,
Hitachi	1445, 0047, 0054, 0017, 0000, 0156, 0051, 0150, 0178, 0030, 1145, 0145, 1256, 0037, 0548, 0634, 1037, 1137, 0036, 0108, 0225, 0508, 0719, 0744, 0578, 0576, 0499, 0492, 0481, 0480, 0797, 0877, 1045, 1149, 1150, 1156, 1225, 1245, 1378, 1481, 1576, 1904, 0009, 0016, 0018, 0019, 0027, 0032, 0035, 0038, 0039, 0044, 0055, 0056, 0092, 0105, 0109, 0151, 0157, 0163, 0165, 0179, 0185, 0186, 0217, 0282, 0343, 0381, 0473, 0474
Hitachi Fujian	0150, 0108, 0860
Hitec	0698
Hitsu	0610, 0218, 0455, 0009
Hoeher	0714, 0865, 1163, 1556
Home Elec.	0606
Hongmei	0093, 0264, 0009, 0817
Hongyan	0264, 0412, 0817
Hornyphon	0037, 0012
Hoshai	0218, 0455, 0282
HP	1088, 1089, 1494, 1502, 1642
Hua Tun	0009, 1150
Huafa	0145, 0009
Huanghaimei	0009
Huanghe	0009, 0817
Huanglong	0009
Huangshan	0264, 0009, 0412, 0817
Huanyu	0264, 0217, 0374, 0817
Huaqiang	0264, 0412
Huari	0145, 0264, 0412
Hugoson	0890, 1217
Huodateji	0051
Hygashi	0217
Hyper	0009, 0217, 0247
Hypersonic	0361
Hypson	0556, 0037, 0714, 0668, 1037, 0486, 0264, 0455, 0217, 0282
Hyundai	0753, 0849, 0860, 0865, 1376, 1531, 1556, 1598
Iberia	0037
ICE	0037, 0264, 0218, 0217, 0371
ICeS	0218
IISonic	1376
Iiyama	0877, 0890, 1217
iLo	1603, 1684
Ima	0236, 0180, 0178, 0179
Imperial	0037, 0370, 0074, 0247, 0418
Imperial Crown	0264, 0009, 0374, 0412, 0661
Indiana	0037
Infinity	0054
Ingelen	0714, 0610, 0487, 0163
Ingersol	0009
Initial	1603

Downloaded From TheatreSystem-Manual.com Manuals

Inno Hit	0218, 0009, 0217, 0247, 0282, 1163
Innova	0037
Innovation	0519
Innowert	0865, 1298
Inotech	0773, 0820
Insignia	1564, 0171, 1204, 1326, 1517, 1641, 2002
Inteq	0017, 0145
Interbuy	0037, 0264, 0009, 0247
Interfunk	0037, 0361, 0012, 0109, 0163, 0200, 0247, 0327, 0512
Internal	0037, 1909
Intervision	0037, 0486, 0487, 0264, 0218, 0455, 0009, 0217, 0247, 0282, 0394, 0519
Irradio	0037, 0218, 0009, 0247, 0371
IRT	0451, 1661, 0698, 0628
Isukai	0037, 0218, 0455, 0282
ITC	0217
ITS	0037, 0264, 0218, 0282, 0371
ITT	0548, 0610, 0361, 0163, 0179, 0208, 0339, 0346, 0473, 0480, 0544
ITT Nokia	0180, 0548, 0195, 0610, 0606, 0361, 0070, 0163, 0179, 0208, 0339, 0346, 0473, 0480
ITV	0037, 0264, 0247, 0374
IX	0877
Janeil	0046
JBL	0054
JCB	0000
JDV	1982
Jean	0156, 0051, 0236, 0036, 0003, 0009, 0092, 0179, 0474
JEC	0035
Jensen	0761, 0815, 0817, 1933
Jiahua	0051
JiaLiCai	0264, 0009, 0412
JIL	0030, 0019
Jinfeng	0051, 0226, 0208, 0817
Jinque	0264, 0009, 0412, 0817
Jinta	0264, 0009, 0412
Jinxing	0054, 0156, 0145, 0556, 0037, 0698, 0264, 0009, 0817
JMB	0556, 0634, 0443, 0499
JNC	1964
Jocel	0712
Johnson	0455
Jubilee	0556
Juhua	0264, 0412, 0817
Jutan	0030, 0019
JVC	1253, 0054, 0093, 0463, 0053, 0030, 0606, 0218, 0036, 0650, 0653, 0508, 0055, 0070, 0371, 0418, 0683, 0731, 1172, 1923
Kaige	0264, 0009, 0412, 0817
Kaisui	0037, 0218, 0455, 0009, 0217, 0282
Kambrook	0217
Kamp	0017, 0180, 0019, 0185, 0217
Kanghua	0896
Kangli	0264, 0009, 0374, 0661, 0817
Kangyi	0264, 0009, 0412
Kapsch	0361, 0163
Karcher	0714, 0610, 0606, 0264, 0370, 0282, 1556
Kathrein	0556
Kawa	0371
Kawasho	0030, 0019, 0185
Kaypani	0052
KB Aristocrat	0163
KDS	1498
KEC	0180, 0060
Ken Brown	0236, 0463
Kendo	0037, 1037, 0610, 0370, 0247, 0362, 0411, 0519, 0648
Kenia	0030, 0019
Kenmore	0146
Kennedy	0163
Kennex	0668, 1037
Kenwood	0180, 0030, 0019
Khind	0706, 0896
KIC	0217
Kiota	0455, 0371
Kioto	0054, 0706, 0556
Kiton	0037, 0668
KLH	0156, 0180, 0765, 0767
KLL	0037
Kloss	0030, 0024, 0046
KMC	0003, 0032
Kneissel	0556, 0037, 0610, 0370, 0362, 0374, 0411, 0499
Kobra	1467
Kolin	0180, 0150, 0053, 0036, 0108, 0033, 0474, 1150, 1331
Kolster	0037, 0218, 0247
Kongque	0264, 0009, 0817
Konichi	0009
Konig	0037
Konka	0180, 0037, 0714, 0218, 0587, 0817, 0754, 0720, 0719, 0707, 0703, 0638, 0632, 0628, 0418, 0371, 0282, 0080
Kontakt	0487
Korpel	0037
Korting	0370, 0039
Kosmos	0037
Kost	1262
Kotron	0412
Koyoda	0009
Kriesler	0012
KTV	0463, 0180, 0030, 0039, 0185, 0217, 0280
Kuaile	0264, 0009, 0412
Kulun	0009
Kunlun	0051, 0264, 0226, 0208, 0374, 0661, 0817
Kyoshu	0032, 0412, 0418
Kyoto	0032, 0163, 0217
L&S Electronic	0714, 0808, 0865
Lark	0154, 0386
LaSAT	0486
Lavis	1037
Leader	0009
Lecson	0037
Legend	0009
Lemair	0032, 0411

Downloaded From TheatreSystem-Manual.com Manuals

Lenco	0037, 1037, 0587, 0374, 0474
Lenoir	0009
Lesa	0247
Lexsor	1196
Leyco	0037, 0264
LG	1423, 0054, 1265, 0060, 0178, 0030, 0556, 0037, 0714, 0698, 0361, 0370, 0108, 1305, 1325, 1378, 1178, 1154, 0856, 0829, 1637, 1758, 0700, 1926, 0644, 0474, 0442, 0247, 0217, 0163, 0109, 0056, 0039, 0038, 0032, 0019, 0009, 0003
Liesenk & Tter	0037
Liesenkotter	0037, 0012, 0327
Lifetec	0037, 0714, 0668, 1037, 1137, 0218, 0009, 0374, 0519, 0683
Lihua	0817
Lloyd's	0236, 0180, 0030, 0009, 0032, 0039, 0056, 0179, 1904
Lloytron	0032
Local Chennai TV	0009
Local India TV	0264, 0009, 0208, 0371, 0602
Local Malaysia TV	0698
Lodos	1037
Loewe	0693, 0037, 0370, 0136, 0512, 0633, 0790
Logik	0236, 0180, 0060, 1037, 0698, 0009, 0011, 0016, 0033, 0056, 0179, 0371, 0773, 0880, 1217
Logix	0668, 0519
Longjiang	0264, 0412, 0817
Luker	1982
Luma	1037, 0009, 0163, 0362, 0374, 0411
Lumatron	0556, 0037, 0361, 0264, 0163, 0217
Lux May	0037, 0009
Luxman	0056
Luxor	0548, 1037, 0361, 0163, 0179, 0208, 0217, 0346, 0473, 0480, 1163
LXI	0047, 0054, 0017, 0154, 0000, 0156, 0051, 0093, 0060, 0053, 0178, 0030, 0171, 0166, 0037, 0036, 0135, 0146, 0159, 0165, 0179, 0208, 0280, 0096, 0056, 0055, 0016, 0018, 0039, 0038, 0035, 0032, 0024, 0021, 0020, 0019
M & S	0054
M Electronic	0037, 0714, 0634, 0195, 0661, 0512, 0492, 0480, 0411, 0374, 0346, 0343, 0287, 0247, 0217, 0163, 0109, 0105, 0009
Macy	0039, 0046, 0186
Madison	0037
MAG	1498
Magnadyne	0054, 0024, 0163, 0187, 0247, 0544
Magnasonic	0054, 0000, 0156, 0093, 0030, 0003, 0019, 0056, 0092, 0109, 0179, 1928
Magnavox	0047, 0054, 0154, 0000, 0250, 0051, 0180, 0060, 0030, 0171, 1454, 0706, 0037, 0036, 1931, 1904, 1755, 1525, 1365, 1254, 1198, 0802, 0780, 0729, 0386, 0282, 0011, 0187, 0186, 0019, 0179, 0020, 0111, 0096, 0092, 0024, 0035
Magnum	0037, 0714, 0648, 1289
Majestic	0017, 0016
Mandor	0264
Manesth	0037, 0264, 0035, 0217
Manhattan	0037, 0668, 1037
Maqma	1467
Marantz	0054, 0030, 1454, 0556, 0037, 0412, 0704, 0854, 0855, 1154, 1398
Mark	0037, 0714, 0009, 0217, 0374
Maruman	0627
Master's	0499
Mastro	0053, 0706, 0698, 0780
Masuda	0037, 0264, 0218, 0009, 0217, 0371
Matsui	1163, 0556, 0037, 0714, 0195, 1037, 0487, 0036, 0455, 0433, 1916, 0744, 0544, 0443, 0371, 0355, 0352, 0335, 0217, 0208, 0177, 0163, 0056, 0039, 0035, 0033, 0011, 0009
Matsushita	0250, 0051, 0650
Matsuviama	0587
Maxdorf	0773
Maxent	0762, 1211, 1755, 1756, 1757
Maxim	1556, 1982
MCE	0009
Meck	0698, 0891
Mediator	0556, 0037, 0012
Medion	0556, 0037, 0714, 0668, 1037, 0698, 1137, 0512, 0808, 0880, 1248, 1900
Megapower	0700
Megas	0610
Megatron	0047, 0178, 0145, 0003, 0009, 0056, 0151
MEI	1037, 0185
Meile	0264, 0412, 0817
Memorex	0154, 0250, 0463, 0180, 0150, 0060, 0178, 0030, 0037, 0195, 1037, 1926, 1911, 0877, 0179, 0165, 0056, 0039, 0035, 0032, 0016, 0009
Memphis	0009
Mercury	0060, 0037, 0009
Mermaid	0037
Metronic	0625
Metz	0037, 0668, 0195, 0587, 0367, 0388, 0447, 0535, 0554, 0746, 1163, 1533
MGA	0150, 0178, 0030, 0218, 0019, 0374
MGN Tech.	0178
Micro Genius	0150
Micromaxx	0037, 0714, 0668, 1037, 0808

Downloaded From TheatreSystem-Manual.com Manuals

Microstar	0808
MicroTEK	0820, 0860
Midland	0047, 0017, 0051, 0018, 0019, 0032, 0039, 0056, 0135
Mikomi	1037, 1149
Minato	0556, 0037
Minerva	0195, 0487, 0108, 0070, 0535, 0554
Minoka	0037, 0412
Mintek	1603
Minutz	0021
Mirror	1900
Mitsubishi	0150, 0868, 0154, 0250, 0093, 0236, 0180, 1250, 0178, 0030, 0556, 0037, 0195, 1037, 0036, 0108, 1171, 1150, 1182, 0836, 0817, 1917, 0535, 0512, 0474, 0381, 0179, 0056, 0033, 0019, 0011
Mivar	0217, 0609
Monaco	0009
Monivision	0700, 0843
Morgan's	0037
Motorola	0054, 0051, 0093, 0150, 0055
MTC	0180, 0060, 0030, 0370, 0011, 0019, 0032, 0039, 0056, 0092, 0185, 0282, 0512
MTEC	0032
MTlogic	0714
Mudan	0051, 0264, 0226, 0009, 0208, 0412, 0817
Multitec	0037, 0668, 1037, 0486, 1556
Multitech	0180, 0037, 0486, 0264, 0370, 0009, 0179, 0217, 0247
Murphy	0032, 0039, 0163, 0474
Musikland	0218, 0247
Mx Onda	1498
Myryad	0556
NAD	0156, 0178, 0166, 0037, 0361, 0019, 0056, 0866, 1156
Naiko	0037, 0606, 1982
Nakimura	0037, 0374
Nanbao	0264, 0009, 0412
Nansheng	0264, 0412, 0817
Narita	1982
NAT	0226
National	0051, 0226, 0508, 0055, 0208
NEC	1398, 0047, 0154, 0156, 0051, 0053, 0178, 0030, 0264, 0036, 0455, 0653, 0508, 0499, 0603, 0661, 0704, 0817, 0882, 1150, 1182, 1378, 1456, 1704, 0497, 0474, 0412, 0381, 0374, 0217, 0186, 0170, 0165, 0056, 0046, 0019, 0016, 0011, 0009
Neckermann	0556, 0037, 0370, 0200, 0247, 0327, 0411, 0418, 0554
NEI	0037, 0163, 0371
Neovia	0865, 1376, 1964
Nesco	0179, 0247
Netsat	0037
NetTV	0762, 1755
Network	0032
Neufunk	0556, 0037, 0714, 0610, 0218, 0009
New Tech	0556, 0037, 0009, 0056, 0217, 0343
New World	0218
Newave	0093, 0178, 0009, 0092, 1150
Nextier	1598
Nicam	0544
Nikkai	0037, 0264, 0218, 0036, 0009, 0032, 0035, 0163, 0179, 0217
Nikkei	0714
Nikko	0178, 0030, 0092
Nikkodo	0178, 0030, 0092
Nintaus	0891
Nishi	0030, 0018
Noblex	0154, 0037, 0264, 0018, 0052
Nobliko	0070
Nogamatic	0109
Nokia	0180, 0548, 0610, 0606, 0361, 0163, 0179, 0208, 0339, 0346, 0374, 0473, 0480, 0492
Norcent	0748, 0824, 1089, 1365, 1590
Nordic	0217
Nordmende	0037, 0714, 0560, 0195, 0109, 0287, 0343, 0891
Normerel	0037
Noshi	0018
Novak	0012
Novatronic	0037, 0105, 0374
NTC	0092
Nu-Tec	0698, 0455, 0820
Nyon	0000
Oceanic	0548, 0361, 0163, 0208, 0473
Odeon	0264
Okano	0037, 0264, 0370, 0009
Olevia	1144, 1240, 1331, 1610
Olidata	1376
Omega	0264
Omni	0748, 0698, 0780, 0826, 0872, 0891
Onida	0053, 1253
Onimax	0714
Onking	0280
Onwa	0180, 0218, 0433, 0371, 0602
Opera	0037
Optimus	0154, 0250, 0093, 0180, 0150, 0178, 0030, 0166, 0650, 0016, 0032, 0039, 0056, 0165
Optoma	0887, 1348
Optonica	0093, 0165
Orbit	0037
Origo	0003
Orion	0443, 0017, 0236, 0463, 0180, 0178, 0556, 0037, 0714, 0264, 1954, 1929, 1916, 1911, 1463, 1196, 0880, 0544, 0474, 0443, 0412, 0355, 0179, 0177, 0019, 0011
Orline	0037, 0218
Ormond	0668, 1037
Osaki	0556, 0037, 0264, 0218, 0032, 0217, 0355, 0374, 0412, 0474
Osio	0037

Downloaded From TheatreSystem-Manual.com Manuals

Oso	0218
Osume	0037, 0218, 0036, 0032, 0038, 0039, 0157, 0474
Otic	1498
Otto Versand	0093, 0556, 0037, 0195, 0361, 0036, 0226, 0109, 0217, 0247, 0343, 0512, 0535, 0544, 0554
Pace	0019, 0092
Pacific	0556, 0037, 0714, 1037, 1137, 0443, 1935
Packard Bell	0092, 1314
Palladium	0556, 0037, 0714, 0370, 1137, 0163, 0200, 0217, 0247, 0327, 0411, 0418, 0519, 0554
Palsonic	0037, 0698, 0264, 0218, 0217, 0418, 0773, 1196, 1269, 1904
Panama	0037, 0264, 0009, 0217, 0247
Panasonic	0054, 0000, 0156, 0250, 0051, 0236, 0030, 0037, 0548, 0361, 0650, 0108, 0225, 0226, 0508, 1271, 1291, 1177, 1175, 1310, 1410, 1480, 1650, 1919, 1941, 1168, 0896, 0853, 0423, 0367, 0208, 0163, 0055, 0052, 0035, 0024, 0018, 1335
Panavision	0037, 0411
Panda	0051, 0706, 0698, 0264, 0226, 0508, 0009, 0208, 0412, 0780, 0817, 0826, 0891
Pathe Cinema	0163
Pathe Marc.	0109
Pausa	0009, 0179
Paxonic	0060, 0030, 0019, 0032, 0039
PCE	0156, 0060, 0179
Peng Sheng	0891
Penney	0047, 0000, 0156, 0250, 0051, 0060, 0178, 0030, 0037, 0036, 0108, 0159, 1347, 0135, 0070, 1378, 1919, 1926, 0056, 0046, 0039, 0038, 0035, 0032, 0027, 0021, 0019, 0018, 0016, 0003
Perdio	0037, 0163, 0282
Perfekt	0037
Petters	1523
Phase	0032
Philco	0054, 0451, 0463, 0180, 0178, 0030, 0145, 1661, 0037, 0370, 0628, 0474, 0774, 0418, 0381, 0247, 0187, 1911, 0186, 0179, 0163, 0096, 0092, 0074, 0056, 0038, 0033, 0032, 0024, 0020, 0019
Philharmonic	0217
Philips	0054, 0017, 0000, 0051, 0178, 0030, 0171, 1454, 0556, 0037, 0361, 0108, 1154, 0774, 0690, 1254, 0554, 0512, 1455, 0474, 0423, 0374, 1756, 0343, 0200, 0187, 0186, 0009, 0096, 0092, 0080, 0056, 0012, 0019, 0032, 0027, 0024, 0020
Phocus	0714, 1289, 1308
Phoenix	0037, 0486, 0370, 0163
Phonola	0556, 0037, 0012, 0080
Pilot	0051, 0060, 0178, 0030, 0706, 0712, 0011, 0019, 0039, 0052, 0056
Pioneer	0166, 0037, 0486, 0361, 0370, 1398, 1260, 0866, 0760, 0679, 0512, 0423, 0287, 0170, 0163, 0109, 0055, 0038, 0011
Pionier	0486, 0370, 1556
Plantron	0037, 0264, 0009
Playsonic	0037, 0714, 0217, 0339
Polaroid	0765, 0865, 1262, 1276, 1314, 1316, 1326, 1327, 1328, 1341, 1498, 1523, 1991, 1992
Polytron	0282
Poppy	0009
Portland	0451, 0003, 0019, 0032, 0039, 0092, 0374
Powerpoint	0037, 0698, 0487
Prandoni-Prince	0361, 0247
Precision	0236, 0180, 0177, 0185, 0217, 0282
Premier	0264, 0009
President	0860
Prima	1196, 0761, 0264, 0009, 0032, 0412, 0474, 0753, 0783, 0815, 0817, 1269, 1933
Princeton	0700, 0717
Prinston	1037
Prinz	0361, 0544
Prism	0250, 0051, 0055
Profex	0361, 0009, 0163
Profi	0009
Profilo	1556
Profitronic	0037
Proline	1376, 0037, 0625, 0634, 1037, 0012, 0411
Proscan	0047, 1447, 0018, 0135, 0466, 1347, 1922
Prosco	0156
Prosonic	0037, 0714, 0668, 0370, 0217, 0371, 0374
Protec	0037, 0264, 0009, 0217, 0247
Protech	0037, 0668, 1037, 0486, 0264, 0009, 0217, 0247, 0282, 0418
Proton	0178, 0030, 0003, 0009, 0039, 0052, 0056, 0466, 0474, 0644, 1092
Proview	1498
ProVision	0556, 0037, 0714, 1037
Pulsar	0017, 0016, 0019, 0092
Pulser	0178, 0019, 0092
Pye	0556, 0037, 0012, 0374, 0412, 0554
Pymi	0009
Qingdao	0051, 0264, 0226, 0208, 0412, 0817

Downloaded From TheatreSystem-Manual.com Manuals

Quadral 0051, 0218
Qualcraft 0039
Quartz 0150, 0178, 0046
Quasar 0250, 0051, 0650, 0009, 0016, 0024, 0035, 0055, 0165, 0247, 0474, 0865, 1919
Quelle 0037, 0668, 0195, 1037, 0361, 0554, 0544, 0535, 0512, 0327, 0247, 0200, 0109, 0074, 0070, 0032, 0011
Questa 0036, 0032
Questar 0036
R-Line 0037
Rabbit 0047
Radialva 0218, 0163
Radiola 0556, 0037, 0012, 0217
Radiomarelli 0037, 0247
RadioShack 0047, 0154, 0180, 0150, 0178, 0030, 0037, 0019, 0032, 0039, 0056, 0165, 1904
Radiotone 0037, 0668, 1037, 0264, 0370, 0009, 0412, 0418, 0648
Rank 0070
Rank Arena 0036, 0602, 0753
RBM 0070
RCA 0047, 0054, 0000, 0051, 0093, 0060, 0178, 0030, 1447, 1454, 0625, 0560, 0618, 2002, 1922, 1919, 1917, 1547, 0018, 0019, 1347, 1247, 1147, 1047, 0774, 0753, 0679, 0021, 0038, 0090, 0165, 0157, 0135, 0092
Realistic 0047, 0154, 0180, 0150, 0178, 0030, 0003, 0016, 0019, 0032, 0039, 0056, 0165
Recor 0037, 0418
Rectiligne 0037
Rediffusion 0548, 0361, 0036, 0163, 0346
Redstar 0037
Reflex 0037, 0668, 1037
Relisys 0865, 0877, 0878, 1211, 1298
Remotec 0250, 0093, 0145, 0171, 0037, 0376, 0424, 0509, 0627
Reoc 0714
Revox 0037
Rex 0264, 0163, 0247, 0411
RFT 0037, 0264
Rhapsody 0185
Rinex 0773
Road Authority . 0282
Roadstar 0037, 0714, 0668, 1037, 0264, 0218, 0009, 0282, 0418, 1189, 1900
Rover 0036, 0877
Rowa 0748, 0037, 0698, 0712, 0264, 0587, 0009, 0817
Royal 0825
Royal Lux 0370, 0335, 0412
Runco 0017, 0060, 0030, 0016, 0497, 0603, 1398
Ruyi 0817
Saba 0250, 0625, 0548, 0714, 0560, 0361, 0109, 0163, 0287, 0335, 0343, 0498
Sagem 0610, 0455, 0618, 0830
Saige 0009, 0817
Saisho 0264, 0009, 0011, 0033, 0163, 0177, 0217, 0544
Saivod 0037, 0668, 1037, 0712, 1163, 1556, 1982
Sakai 0163
Sakyno 0455
Salora 0548, 0361, 0163, 0208, 0480
Salsa 0335
Sampo 0047, 0154, 0093, 0178, 0030, 0171, 0036, 0650, 1756, 1755, 0762, 0700, 0474, 0092, 0052, 0039, 0032, 0009
Samsung 1249, 1619, 0060, 0054, 0017, 0154, 0156, 0093, 0047, 0812, 0702, 0178, 0030, 0556, 0037, 0264, 0370, 0036, 0587, 0618, 0226, 1060, 0817, 1150, 0814, 1235, 0774, 0766, 1312, 0718, 1584, 0644, 1630, 1903, 0009, 0019, 0032, 0035, 0039, 0055, 0056, 0090, 0092, 0163, 0179, 0208, 0217, 0362, 0371, 0474, 0519
Samsux 0038, 0039
Sandra 0217
Sanjian 0264, 0412
Sanky 0060, 0030, 0019, 0038, 0039, 0280
Sansei 0451, 0092
Sansui 0463, 0060, 0030, 0706, 0037, 0714, 0455, 1935, 1929, 1911, 1904, 1537, 1531, 0826, 0753, 0729, 0602, 0371, 0165, 0019
Santon 0009
Sanyo 0047, 0054, 0154, 0000, 0156, 0463, 0180, 0145, 0171, 0037, 0264, 0370, 0036, 0108, 0508, 0412, 0424, 0474, 0544, 0704, 0798, 0799, 0893, 1755, 1208, 1142, 1150, 1154, 1179, 0381, 0376, 0339, 0280, 0217, 0208, 0170, 0163, 0159, 0157, 0146, 0105, 0088, 0046, 0011, 0009
Sanyong 0037
Sanyuan 0093, 0009, 0817
Saville 0060
SBR 0556, 0037, 0012
Sceptre 0878, 1217, 1360, 1599
Schaub Lorenz . 0548, 0714, 0486, 0606, 0361, 0374
Schneider 0556, 0037, 0714, 0668, 1037, 0361, 1137, 0218, 1982, 1904, 0648, 0544, 0519, 0394, 0371, 0352, 0343, 0247, 0217, 0163, 0070, 0012
Scimitsu 0019
Scotch 0178

Downloaded From TheatreSystem-Manual.com Manuals

Scotland	0163
Scott	0236, 0180, 0178, 0030, 0019, 0039, 0177, 0179, 1189
Sears	0047, 0054, 0017, 0154, 0000, 0156, 0051, 0093, 0060, 0053, 0178, 0030, 0171, 0166, 0037, 0036, 0159, 0165, 0179, 0208, 0280, 1904, 1926, 0146, 0135, 0096, 0056, 0055, 0039, 0038, 0035, 0032, 0024, 0021, 0020, 0019, 0018, 0016
Seaway	0634
Seelver	1037
SEG	0037, 0668, 1037, 0487, 0264, 0218, 0036, 0009, 0217, 0247, 0362, 1163
SEI	0037, 0163, 0177, 0544
Sei-Sinudyne	0037, 0544
Seimitsu	0019
Seleco	0264, 0163, 0346, 0362, 0371, 0411, 1351
Semivox	0236, 0463, 0180
Semp	0156, 1356
Sencora	0009
Sentra	0035
Serie Dorada	0156, 0180, 0178, 0030, 0019, 0056
Serino	0093, 0610, 0455
Shancha	0264, 0412, 0817
Shanghai	0264, 0226, 0009, 0208, 0412, 0817
Shaofeng	0145, 0817
Sharp	1393, 0818, 0093, 1602, 0054, 0180, 0053, 0030, 0668, 0036, 0650, 0653, 1193, 0688, 0689, 0720, 0787, 0851, 1165, 1917, 0491, 0474, 0386, 0256, 0200, 0179, 0165, 0157, 0039, 0032, 0019, 0009
Shen Ying	0003, 0009, 0092, 0179, 0474
Shencai	0145, 0264, 0009, 0412
Sheng Chia	0093, 0236, 0009, 0033, 0179, 0474, 1150
Shenyang	0264, 0009, 0696, 0753, 0817
Sherwood	0009
Shintoshi	0037
Shivaki	0178, 0556, 0037, 0374, 0443
Shogun	0019
Shorai	0179
Show	0009, 0418
Siam	0037
Siarem	0163
Siemens	0145, 0037, 0195, 0032, 0146, 0157, 0200, 0327, 0535, 0554
Siera	0556, 0037, 0012
Siesta	0370
Signature	0047, 0093, 0030, 0016, 0165, 0179, 0187
Signet	1262
Silva	0037, 0361, 0648
Silva Schneider	0037, 1556
Silvano	0587
Silver	0361, 0036, 0455, 0019, 0179
SilverCrest	1037
Simpson	0178, 0030, 0011, 0186, 0187
Singer	0060, 0037, 0433, 0009, 0092, 0247, 0335, 0371, 0891, 1537
Sinotec	0773
Sinudyne	0037, 0361, 0163, 0177, 0544
Skantic	0163
SKY	0037, 0282, 0880
Sky Brazil	0880
Sky-North	0037
Skygiant	0180
Skysonic	0696, 0753
Skyworth	0748, 0037, 0698, 0264, 0009, 0696, 0753, 0817, 0825
Sliding	0865, 0880
SLX	0668
Smaragd	0487
Soemtron	0865, 1298
Solar Drape	0000, 0032
Solavox	0037, 0548, 0361, 0032, 0163
Sole	0813
Sonawa	0218
Songba	0009
Soniko	0037
Soniq	1467
Sonitron	0370, 0208, 0217, 0339
Sonix	1376
Sonneclair	0037
Sonoko	0037, 0264, 0009, 0217, 0282
Sonolor	0548, 0361, 0163, 0208, 0282
Sontec	0037, 0370, 0009
Sony	0000, 0834, 1599, 0017, 0154, 1100, 0150, 0053, 0037, 1505, 0036, 0650, 1925, 1904, 1751, 1685, 1651, 1619, 0011, 1317, 1300, 1167, 0074, 0810, 0080, 0632, 0353, 0157, 0111
Sound & Vision	0218, 0374
Soundesign	0180, 0178, 0019, 0056, 0179, 0186
Soundwave	0037, 0032, 0418
Sowa	0156, 0051, 0060, 0178, 0036, 0226, 0092, 0474, 1150
Soyea	0773
Spectra	0009
Spectravision	0156, 0178, 0159, 0179, 0186
Spectricon	0003, 0032
Spectroniq	1498
Squareview	0171
SR2000	0154, 0171
Ssangyong	0009, 0032
SSS	0180, 0019
Stag	0032
Staksonic	0009
Standard	0037, 1037, 0218, 0009, 0217, 0374
Standard Comps	0218, 0009
Starlite	0236, 0180, 0037, 0264, 0009, 0019, 0163
Stenway	0218, 0282
Stern	0264, 0163, 0411
Stevison	1982

Downloaded From TheatreSystem-Manual.com Manuals

Strato 0037, 0264, 0009
Strong 1149, 1163
Studio Experience 0843
Stylandia 0217
Sunkai 0610, 0487, 0218, 0455, 0355, 0865
Sunstar..... 0037, 0264, 0009, 0371
Sunwatt..... 0455
Sunwood..... 0037
Superla..... 0217
Superscan 0093, 0864
Supersonic..... 0455, 0009, 0208, 1189
SuperTech 0556, 0037, 0218, 0009
Supra 0178, 0009, 0039, 0056, 0374
Supre-Macy 0039, 0046, 0186
Supreme..... 0000
Susumu 0218, 0287, 0335, 0474
Sutron 0009
SV2000 0054
SVA..... 0748, 0587, 0768, 0865, 0870, 0871, 0872
Svasa 0455
Swisstec..... 0880
Sydney 0217
Sylvania..... 1271, 0047, 0054, 0154, 0000, 0051, 0178, 0030, 0171, 0037, 0036, 0381, 1314, 1394, 1904, 1926, 1931, 0187, 0186, 0179, 0159, 0096, 0092, 0056, 0024, 0020
Symphonic 0000, 0180, 0178, 0171, 0179, 1904
Synco 0000, 0451, 0093, 0060, 0178, 0036, 0092, 0474
Syntax 1144, 1240, 1331
Sysline..... 0037
T+A..... 0447
Tacico 0178, 0009, 0092, 0179, 0474, 1150
Tai Yi 0009, 1150
Taishan 0009, 0374, 0817
Talent 0178
Tandberg..... 0361, 0109, 0367
Tandy 0093, 0218, 0039, 0163, 0165, 0217, 0247
Tashiko 0036, 0650, 0032, 0033, 0092, 0146, 0163, 0170, 0217, 1150
Tatung 0054, 0154, 0000, 0156, 0051, 0060, 0037, 0036, 0038, 0033, 0055, 0011, 0009, 0003, 0217, 0474, 1150, 1156, 1248, 1254, 1556, 1756
TCC 0826
TCL..... 0706, 0698, 0412, 0826, 1537
TCM..... 0714, 0808, 1289
Teac 0706, 0154, 0178, 0171, 0037, 0714, 0668, 1909, 1037, 0698, 0712, 0264, 0455, 0418, 0512, 0544, 0412, 0689, 0282, 0217, 0170, 0159, 0146, 1149, 1755, 1904, 0009
Tec 0037, 0009, 0163, 0217, 0247, 0335, 0474
Tech Line 0037, 0668, 1163
Tech Lux..... 1189
Techica..... 0218
Technica..... 1982
Technics..... 0054, 0250, 0051, 0556, 0650, 0226, 0046, 0055
TechniSat 0556
Technisson..... 0714, 1289
Technol Ace 0179
Technosonic..... 0556, 0499
Technotrend 1531
Technovox 0030, 0217
Techview 0847
Techwood 0250, 0051, 0060, 0003, 0055, 0056, 1163
Tecnimagen..... 0556
Teco 0051, 0093, 0178, 0264, 0218, 0036, 0653, 0009, 0092, 0280, 0474
Tedelex..... 0698, 0606, 0009, 0208, 0217, 0418, 0891, 1537
Teiron 0009
Tek..... 0820
Teknika..... 0054, 0463, 0180, 0150, 0060, 0178, 0016, 0019, 0032, 0039, 0046, 0056, 0092, 0179, 0186
Teleavia 0287, 0343
Telecolor 0017
Telecor 0037, 0218, 0163, 0217, 0394
Telefunken..... 0702, 0037, 0625, 0714, 0560, 0486, 0698, 0712, 0587, 0498, 0346, 0343, 0335, 0287, 0109, 0074, 0056, 0753, 0754, 0820, 0896, 1556
Telefusion 0037
Telegazi..... 0037, 0264, 0218, 0163
Telemeister 0037
Telesonic 0037
Telestar..... 0556, 0037, 0009
Teletech..... 0037, 0668, 1037, 0009, 0247
Teleton..... 0036, 0179, 0186, 0217
Televideon 0163
Teleview..... 0037
Tempest..... 0264, 0455, 0009
Tennessee 0037
Tensai 0037, 1037, 0218, 0009, 0105, 0217, 0247, 0371, 00374
Tenson 0009
Tera..... 0030, 0092, 0466, 0474
Tevion 0556, 0037, 0714, 0668, 1037, 1137, 0648, 0767, 0808, 1248, 1259, 1289, 1298, 1498, 1556
Texet 0218, 0009, 0217, 0374
Texla 0780
ThemeScene 0887
Thomas 0047, 0178, 0019, 0039, 0056, 1904
Thomson 0047, 1447, 0037, 0625, 0560, 0109, 0287, 0335, 0343
Thorn 0037, 0361, 0264, 0036, 0035, 0074, 0109, 0163, 0335, 0343, 0499, 0512, 0535
Thorn-Ferguson 0335, 0343, 0499

Downloaded From TheatreSystem-Manual.com Manuals

Tiane	0093, 0817
Tiny	1269
Tiny Digital	0660
TMK	0236, 0180, 0178, 0056, 0177
TML	1756
TNCi	0017
Tobishi	0218
Tobo	0748, 0264, 0009, 0412
Tocom	0156
Tokai	0037, 0668, 1037, 0009, 0163, 0217, 0374
Tokaido	1037
Tokyo	0035
Tomashi	0218, 0282
Tongguang	0264, 0412
Tongtel	0587, 0780
Tophouse	0180, 0672
Topline	0668, 1037
Toshiba	1163, 1256, 1508, 1306, 0156, 1524, 0154, 0093, 0150, 1265, 0060, 1145, 0145, 0166, 0195, 1037, 0264, 0036, 0618, 0650, 0508, 1325, 1289, 1343, 1356, 1360, 1369, 1456, 1556, 1635, 1656, 1704, 1918, 1935, 1936, 0009, 0011, 0035, 0070, 0109, 0217, 0381, 0412, 0423, 0509, 0644, 0718, 0832, 0845, 1150, 1156, 1169, 1173
Tosonic	0185
Totevision	0051, 0039
Towada	0217
Toyoda	0264, 0009, 0371
Toyomenka	0178
Trakton	0264, 0217
Trans Continens	0037, 0668, 1037, 0217
TRANS-conts	0556, 0865
Transonic	0037, 0698, 0712, 0264, 0455, 0587, 0009, 0418, 0512, 0780
Triad	0556, 0218
Trical	0157
Trident	0217
Trio	1498
Tristar	0264, 0218
Triumph	0556, 0037, 0177, 0346
Truetone	0250, 0051, 0055
Tsoschi	0282
Tuntex	0030, 0009, 0092, 0474
TVS	0463
TVTEXT 95	0556
Uher	0037, 0486, 0370, 0019, 0374, 0418, 0480
Ultra	0019, 0039, 0092
Ultravox	0037, 0163, 0247, 0374
Unic Line	0037, 0455, 0473
Unitech	0039
United	0037, 0714, 1037, 0587, 1916, 1982
Universal	0047, 0037, 0714, 0021, 0027, 0135
Universum	0037, 0668, 0195, 1037, 0361, 0264, 0370, 0036, 0618, 0362, 0411, 0418, 0473, 0474, 0480, 0492, 0512, 0535, 0544, 0554, 1163, 0346, 0327, 0247, 0217, 0200, 0177, 0170, 0157, 0146, 0109, 0105, 0074, 0070, 0032, 0011, 0009
Univox	0037, 0163
V	0864, 0885, 1755, 1756
V2max	0865
V7 Videoseven	0880, 1217, 1376, 1755
Vector Research	0030
Vestel	0037, 0668, 1037, 0217, 1163
Vexa	0037, 0009
Victor	0250, 0053, 0036, 0650, 0653, 0376
Videocon	0037, 0508
Videologic	0218
Videologique	0218, 0217
Videomac	0009
Videosat	0247
VideoSystem	0037
Videotechnic	0217, 0374
Videoton	0163
Vidikron	0054, 1398
Vidtech	0178, 0036, 0019
Viewsonic	0797, 0857, 0864, 0885, 1330, 1578, 1627, 1640, 1755
Viking	0060, 0046
Vision	0037, 0264, 0032, 0217, 0474
Vizio	1758, 0864, 0885, 1499, 1755, 1756
Vortec	0037
Voxson	0178, 0037, 0163, 0418
Waltham	0037, 0668, 1037, 0109, 0217, 0418, 0443
Wards	0047, 0054, 0017, 0154, 0000, 0156, 0051, 0093, 0236, 0180, 0060, 0178, 0030, 0166, 0037, 0195, 0020, 0019, 0165, 0179, 0018, 0186, 0187, 0016, 0866, 1147, 1156, 1347, 0151, 0135, 0111, 0096, 0021, 0080, 0024, 0056, 0055, 0027, 0033, 0046, 0039, 0038, 0035
Warumaia	0374, 0661
Watson	0037, 0714, 0668, 1037, 0218, 0009, 0163, 0394, 0519, 1376
Watt Radio	0163, 0544
Waycon	0156
Wega	0037, 0036
Wegavox	0009
Weipai	0009
Welltech	0714
Weltblick	0217
Welton	0178, 0019
Weltstar	1037
Westinghouse	0885, 0000, 0451, 0003, 0889, 0890, 1092, 1282, 1577
Wharfedale	0556, 0037, 0519, 0860, 0891, 0896, 1556
White Westinghs	0451, 0236, 0463, 0037, 1909, 0179, 0186, 0623, 0889
Winco	0412
Windsor	0668, 1037

Downloaded From TheatreSystem-Manual.com Manuals

Windstar	0282
Windy Sam	0556
Wintel	0714
World	0451, 0236, 0463, 0180
World-of-Vision	0865, 0877, 0880, 0890, 1217, 1289, 1298
Worldview	0455
Wyse	1365
Xenius	0634, 0661
Xiahua	0698, 0264, 0009, 0412, 0773, 0817
Xianghai	0009
Xiangyang	0264, 0412
Xiangyu	0009
Xihu	0264, 0412, 0817
Xinaghai	0412
Xingfu	0009
Xinghai	0264
XLogic	0698, 0860
Xoro	1196, 1217
XR-1000	0154, 0180, 0171, 0016, 0096, 0179
Xrypton	0037
Yamaha	0030, 0650, 0019, 0769, 0797, 0833, 0838, 0839, 1576
Yamishi	0037, 0218, 0455, 0217, 0282
Yapshe	0250
Yingge	0009
Yokan	0037
Yoko	0037, 0264, 0370, 0218, 0009, 0217, 0247, 0339
Yonggu	0009
Yorx	0030, 0218
Youlanasi	0817
Yousida	0009
Ytawai	1531
Yuhang	0009
Zanussi	0264, 0163, 0217
Zenith	0047, 0017, 0000, 0093, 0463, 1265, 0812, 0178, 0030, 1145, 0145, 0171, 0037, 1909, 0146, 0092, 0039, 0016, 1305, 1904, 1911, 1929
Zenor	0339
ZhuHai	0009, 0374
Zonda	0698, 0003

CBL

3M	0033
A-Mark	0144, 0277, 0008, 0040
ABC	0237, 0014, 0003, 0008, 0007, 0011, 0013, 0017, 0033
Accuphase	0014, 0003, 0007, 0011, 0013, 0017
Acorn	0237
Action	0237
Active	0237
ADB	1082, 1230, 1269, 1927
Aichi Denshi	1512
Aim	0015
Allegro	0153, 0315
American	0060
Americast	0899
Amstrad	1222
Archer	0237, 0153, 0797
Auna	0277, 1230, 1269
Austar	0276, 0012
BCC	0276
Bell & Howell	0014
Bell South	0899
Birmingham Cable Comms	0276
British Telecom	0003
Cable & Wireless	1068
Canal+	0443
Century	0008, 0153, 0315
Citation	0017
Citizen	0153, 0242, 0315
Clearmaster	0883
ClearMax	0883
Colour Voice	0025, 0031
Comcor	1522
Comcrypt	0443
Comtec	0019
Comtronics	0040, 0060
Contec	0019
Cool Box	0883
Coolmax	0883
Curtis Mathes	0015, 0242
Daeryung	0877, 1877, 0477, 0277, 0008
Dalvi	1522
Digeo	1187
Digi	0637
Director	0476
Dumont	0637
DX Antenna	1500, 1502
Eastern	0002, 0418
Emerson	0014, 0015, 0797
Encon	0008
Everquest	0015, 0040
Fastweb	1630
Filmnet	0443
Focus	0400
Force	1798
Fosgate	0276
Foxtel	1222
France Telecom	0817
Freebox	1482
Fujitsu	1497
Funai	0019
Galaxi	0008
Garrard	0153
GC Electronics	0040
GE	0237, 0144, 0021
Gehua	0476
Gemini	0015, 0070, 0242, 0400, 0797
General Instr.	0476, 0810, 0014, 0276, 0003, 0012, 0011, 0015, 0024
Getterson	0040
Gibralter	0003
GMI	0015, 0797, 0883
Golden Channel	1110
GoldStar	0144, 0040
Goodmind	0797
Hamlin	0009, 0273, 0015
Hitachi	0009, 0014, 0003, 0008, 0011, 0033
Houston	0011
Humax	1813
Hytek	0007
Hytex	0007
Insight	0476, 0810
Jasco	0015, 0153, 0315
Jebsee	0014, 0400
Jerrold	0476, 0810, 0014, 0276, 0003, 0012, 0011, 0015, 0024, 0031
Kabel Deutschld	1981
Kabelvision	0003

Downloaded From TheatreSystem-Manual.com Manuals

Kloss	0277
KNC	0008
Kuang Yu	0024
Leon	0015
LG	0144, 0040
Macab	0817
Macom	0033
Madritel	1230
Magnavox	0014, 0797
Maspro	1510
Matav	1082
Melita	0003
Mellenium	0153
Memorex	0000
Mitsubishi	0003
MNET	0019, 0443
Mood	1386
Motorola	1376, 0476, 0810, 1187, 1254, 0014, 0276, 1106, 0400, 1540
MS	0015
Multichoice	0019, 0443
Multitech	0883
MultiVision	0012
NEC	1496
Nikkai	0153
Nokia	1569
Noos	0817, 1624
Nova Vision	0277, 0008
Novaplex	0277, 0008, 0017
NSC	0012, 0070, 0400, 0637
NTL	1068, 1060, 0276, 0003, 0277
Oak	0019, 0007, 0017
Ono	1068
Optimus	0021
Optus	1060, 0276
Pace	0877, 1877, 0237, 1068, 1060, 0008, 1577
Panama	0107, 0021
Panasonic	0000, 0144, 0107, 0008, 0021, 0040, 0375, 1488
Panther	0637
Paragon	0000, 0525, 0008
Penney	0000, 0637
Philips	0317, 0817, 0013, 0025, 0031, 0060, 0153, 0242, 0290, 1305
Pioneer	0877, 1877, 0144, 0533, 0023, 1021, 1500
Popular Mechs	0400
Prism	0012, 0013
Pulsar	0000, 0040
Pulser	0040
PVP Stereo VM	0003
Quasar	0000
R-Line	0040
RadioShack	0015, 0153, 0315, 0797, 0883
RCA	1256, 0021, 0060, 0797
Realistic	0153
Recoton	0153, 0400
Regal	0279, 0273, 0276
Regency	0002
Rembrandt	0011, 0040, 0070, 0153
Runco	0000
Sagem	0817, 1624
Salora	0000
Samsung	0000, 0144, 1060, 0003, 0023, 0040, 0070, 1666
Satbox	0375
Scientific Atlanta	0877, 1877, 0477, 0237, 0000, 0003, 0277, 0008, 0012, 0017, 0021, 0025, 1510
Sigma	0019
Signal	0011, 0015, 0040
Signature	0011
SL Marx	0040
Sony	1006, 1460
Sprucer	0144, 0021
Starcom	0014, 0003, 0015
Stargate	0014, 0015, 0040, 0797
StarHub	0276, 1927
Starquest	0015
Storm	0637
Suena Madritel	1230
Sumitomo	1500, 1503, 1504
Supercable	0276
Supermax	0883
Tadiran	0040
Tele+1	0443
Teleavia	0040
Telenet	1920
Telepiu	0443
Teletronik	1522
Teleview	0040
Telewest	1068
Telsey	1630
Thomson	1256, 1110, 1582
Time Warner cbl	1877
Timeless	0040, 0418
Tocom	0019, 0012, 0013
Torx	0003
Toshiba	0000, 1509
Trans PX	0276, 0153, 0315
TransACT	1106, 1386
Tristar	0883
TS	0003, 0024
Tusa	0015
TV Comm	0019
TV86	0040
Unika	0153
United Artists	0007, 0024
United Cable	0014, 0276, 0003, 0011
Universal	0153, 0315
UPC	1582
US Electronics	0276, 0003, 0008, 0017
V2	0883
Videoway	0000
Viewmaster	0883
Viewstar	0060
Vision	0883
Visiopass	0817
Vortex View	0883
Zenith	0000, 0525, 0899, 0008, 0015, 0017, 0060, 0153, 0315
Zentek	0400

SAT

@sat	1300, 1831
@Sky	1334
ABsat	0713
ADB	0642, 0887, 0241, 1259, 1367, 1418, 1473, 1491
Aiwa	1514, 1515
Akai	0200
Alba	0455, 0713, 1284, 1659, 1811
Allsat	0200, 0364, 1017

Downloaded From TheatreSystem-Manual.com Manuals

Allsonic..... 0369
Alltech 0713
Allvision 1232, 1334, 1412
AlphaStar 0772
Amitronica..... 0713
Ampere 0132, 0396
Amstrad..... 0847, 1175, 0132, 0338, 0396, 0713, 0885, 1113, 1693, 1801
Anglo 0713
Ankaro 0369, 0713, 1279
AntSat 1017, 1083
Apollo 0455
Arcon 0332, 1075, 1279
Arcus 1143
Arion 1115
Armstrong 0200
Arnion 1300
Asat..... 0200
ASCI..... 0114, 1334
ASLF 0713
AssCom 0853
AST 0321
Aston 1129, 1261
Astra 0607, 0713
Astratec..... 1743
Astro 0173, 0369, 0607, 0658, 1099, 1100, 1113
Atsat 1300, 1831
AtSky 1334
Audioline 1672
Audioton..... 0364
Aurora 0879, 0642, 1433
Austar 0879, 0642, 0494, 1176, 1259
Avalon 0396
Axil 1457, 1659
Axis..... 1111, 0369
B@ytronic 1412
Bauckhage 1331
Beko 0455
Bell ExpressVu . 0775
Bentley Walker . 1017
Best 0369
Big Sat..... 1457
Black Diamond . 1284
Blaupunkt 0173
Blue Sky 0713
Blue Star 1279
Boca..... 0132, 0713, 1232, 1366
Bose 1616
Boston 1251
Brainwave 0332, 0658, 1294, 1672
British Sky Bcasting0847, 1175, 1656, 1662
Broco 0713
BskyB 0847, 1175, 1662
BT..... 1296
Bubu Sat..... 0713
Bush 1284, 1471, 1645, 1672, 1743, 1811
Canal 0853
Canal Digital 0853, 1622, 1780
Canal Satellite .. 0853, 0292, 1339, 1853
Canal+ 0853
Centrex..... 1457
Century..... 0856
CGV..... 1413
Chaparral 0216
Chess 0114, 0713, 1334, 1626
Chili 1718
CityCom..... 0299, 0607, 0818, 1075, 1176, 1232
Classic 1672
Clatronic 0332, 1413
Clemens Kamphus 0396
CNS 1367
Cobra 0396
Colombia..... 0132
Columbia..... 0132
Comag 0132, 1232, 1366, 1412, 1413, 1579
Condor 0369, 0607
Connexions..... 0369, 0396
Conrad 0132, 0369, 0607
Coship 1457
Crossdigital..... 1109
Crown 1284
Cryptovision..... 0455
Cyfra+ 1076
Cyrus 0200
D-box 0723, 1114
Daeryung..... 0396
Daewoo 1111, 0713, 1296, 1743
Deltasat..... 1075
Dgtec 1242, 1542, 1631
Digatron 1294
Digenius..... 0299, 1161
Digiality 0607
Digifusion..... 1645, 1743
DigiLogic 1284
DigiQuest 1300, 1457, 1473
DigiSat 1232
Digisky 1457
DigitAll World .. 1227
Digiturk..... 1076
Digiwave 1631
Dijam 1296
DiPro 1367, 1543
DirecTV..... 1377, 0392, 0566, 0639, 1639, 1142, 0247, 0749, 1749, 0724, 0819, 1856, 1076, 1108, 0099, 1109, 1392, 1414, 1442, 1443, 1444, 1609, 1640
Discoverer 0605
Dish Network Sys1505, 1005, 0775, 1170, 1775
Dishpro..... 1505, 1005, 0775, 1775
Distratel 0885, 1283, 1704
DMT..... 1075
DNT 0200, 0396
Dream Multimedia 1237
DSE 1375
DSTV 0879, 0642, 1433
Dune..... 0369
Durabrand 1284
DX Antenna 1530
Echostar 1505, 1005, 0775, 0853, 0167, 0610, 1200, 1775, 1767, 1473, 1418, 1409, 1323, 1170, 0713, 0455, 0396
Einhell..... 0132, 0713
Elap 0713, 1129, 1567
Electron 1279
Elsat 0713
Elta 0200, 0364, 0369, 1659
Emme Esse 0369
Energy Sistem .. 1631
Engel 0713, 1017, 1251
EP Sat 0455
Esat 0879
Eurieult 0885

Downloaded From TheatreSystem-Manual.com Manuals

Eurocrypt	0455
EuroLine	1251
Europa	0607
Europhon	0132, 0299, 0607
Eurosky	0132, 0114, 0299, 0369, 0607
Eurostar	0607, 0818
Eutelsat	0713
Expressvu	0775, 1775
Eycos	1279
Fagor	0364
Fenner	0369, 0605, 0713
Ferguson	0711, 0455, 1291, 1743
Finepass	1593, 1780
Finlandia	0455
Finlux	0455
Flair Mate	0713
FMD	0114, 1251, 1413, 1457
Fortec Star	1017, 1083
Foxtel	0879, 0720, 0455, 1176, 1356
Fracarro	0125
Freecom	0335
Fresat	0885
FTEmaximal	0369, 0713
Fuba	0173, 0299, 0369, 0396, 1161, 1214, 1251, 1801
Fugionkyo	0125
Funai	1377, 0338
Galaxis	0853, 1111, 0879, 0364, 0369, 1557
Galaxisat	0321
Gardiner	0818
Garnet	1075
GbSAT	1214
GE	0392, 0566
Gecco	1412
General Instr.	0869
General Satellite	1176
Globo	1251, 1334, 1412, 1429, 1626
GOD Digital	0200
GOI	0775, 1775
Gold Box	0853, 0292
Gold Vision	1017, 1631
Golden Interstar	1283
GoldStar	0335
Goodmans	0455, 1246, 1284, 1291
Gradiente	0856, 0099, 0887
Granada	0455
Grothusen	0335
Grundig	0847, 0853, 0173, 0879, 1291
Haensel & Gretel	0132
Handan	1622, 1780
Hanseatic	0605, 1099, 1100
Hantor	0332
Hauppauge	1294, 1672
HB	1214, 1801
HDT	1159
HE@D	1279
Heliocom	0607
Helium	0607
Hills	1232
Hirschmann	1111, 0173, 0125, 0299, 0369, 0396, 0607, 1232, 1412
Hisawa	0332
Hisense	1535
Hitachi	0749, 0819, 0214, 0455, 0489, 0491, 1250, 1284, 1518, 1523, 1525
HNE	0132
Homecast	1214, 1680
Hornet	1300
Houston	0775, 0396
HTS	0775, 1775
Hughes Net Sys	1142, 0749, 1749, 1442, 1443, 1444
Humax	1176, 1427, 1670, 1675, 1743, 1790, 1882, 1915
Hung Chang	0732
Huth	0132, 0332, 0335, 0364, 0607, 1017, 1075, 1143
Hwalin	0885
Hyundai	1075, 1159
iCan	1367
ID Digital	1176
IEEC	0605
ILLUSION sat	1557, 1631
iLo	1535
Imperial	1334, 1429, 1672
Indovision	0887
Ingelen	0114, 0396
Innova	0099
International	0132
Interstar	1017, 1214
Intervision	0364, 0607
Irradio	1331
ISkyB	0887
ITT Nokia	0723, 0455
Jadeworld	0642
Jaeger	1334
Jerrold	0869
JiWon	0364
Johansson	0332, 0364
Jolly	0364
JSR	0364
JVC	0775, 0492, 1170, 1507, 1531, 1532, 1775
K-SAT	0713
Kamm	0713
Kaon	1300, 1583
KaTelco	1111
Kathrein	0173, 0200, 0114, 0480, 0504, 0553, 0658, 0713, 0818, 1416, 1561, 1567, 1706, 1707, 1709
Kennex	0125
Kenwood	0853
Key West	0132
Kiton	0114
Konig	0607
Kosmos	0335
Kreatel	1385
Kreiling	0114, 0658
Kreiselmeyer	0173
L&S Electronic	0132, 0369, 1334
Labgear	1296
LaSAT	0173, 0132, 0299, 0369, 0607
Lava	1631
Legend	1718
Legrand	1718
Lemon	1334
Lenco	0335, 0369, 0607, 0713
Lennox	0369
Lenoxx	1611
LG	0335, 1075, 1226, 1414
Lifesat	0132, 0299, 0369, 0605, 0713
Lodos	1284
Logik	1284
Logix	1017, 1075

Downloaded From TheatreSystem-Manual.com Manuals

Lorenzen	0132, 0299, 0607, 1161, 1294, 1579
Lorraine	0335
Lupus	0369
M Electronic	0818
M vision	1557
M&B	0605
Magnavox	0724, 0722
Manata	0132, 0713
Manhattan	0332, 0364, 0455, 1017, 1083
Marantz	0200
Maspro	0173, 0713, 1520, 1530
Matsui	0173, 0332, 1284, 1743
Matsushita	0214, 0340, 0500
Max	0607
Maximum	1075, 1334
McIntosh	0869
Mediabox	0853, 0292
Mediacom	1206
MediaSat	0853, 0292
Medion	0132, 0299, 0369, 0713, 1075, 1161, 1232, 1334, 1412, 1626
Medison	0713
Mega	0200
Memorex	0724
Metronic	0132, 0713, 0818, 0885, 1279, 1283, 1334, 1375, 1704
Metz	0173
MiCO	1811
Micro	0607, 0713, 1294
Micro Elektronic	0713
Micro Technology	0713
Micromaxx	0299, 0369
Microstar	1075
Microtec	0713
Mitsubishi	0749, 0455, 0491
Morgan's	0200, 0132, 0364, 0713, 1232, 1412
Motorola	0869, 0856, 1473
MTEC	1214
Multibroadcast	0879, 0642
Multichoice	0879, 0642, 1433, 1559, 1560
Muratto	0321, 0335
Mx Onda	1659
Myryad	0200
Mysat	0713
MySky	1693, 1848, 1850
Navex	0332
NEC	0496, 1270, 1519, 1617
NEOTION	1334
Netgem	1322
Netsat	0099, 0887
Neuf TV	1322
Neuhaus	0607, 0713
Neuling	0132, 1232
Neusat	0713, 1279, 1331
Neveling	1161
Nevir	1659
Newton	0396
Next Level	0869
NextWave	0732, 1017, 1143
Nikko	0723, 0200, 0713
Noda Electronic	0885, 1704
Nokia	0853, 0723, 0455, 1023, 1223, 1311, 1723
Nordmende	0455, 1611
Novis	0332
OctalTV	1505, 1294
Omega	0887
Opentel	1232, 1412
Optex	0114, 0364, 0713, 1283, 1611
Optimus	0724
Optus	0879, 1143
Orbis	1232, 1334, 1412
Orbitech	0114, 1099, 1100
P/Sat	1232
Pace	0847, 0853, 0200, 0887, 0720, 1175, 0791, 0455, 0329, 0241, 1323, 1356, 1423, 1623, 1693, 1717, 1848, 1850
Pacific	1284, 1375
Packard Bell	1111
Palcom	0299, 1161, 1331, 1409
Palladium	0396
Panarex	1159
Panasat	0879, 1433
Panasonic	0247, 0701, 0847, 0214, 0340, 0455, 0500, 1304, 1404, 1508, 1526, 1527, 1528
Panda	0173, 0455, 0607
Pansat	1159, 1807
Patriot	0132
Paysat	0724
peeKTon	1457
Philips	1142, 0749, 1749, 0775, 0724, 0819, 0856, 1076, 0722, 0099, 0847, 0853, 0173, 0200, 1114, 0887, 0292, 0818, 0455, 0133, 1442, 1543, 1672
Phonotrend	1200, 0364, 1017
Pilotime	1339
Pino	1334
Pioneer	1142, 0853, 0292, 0329, 0352, 1308, 1442
Planet	0396
PMB	0713, 1611
Polytron	0396
Portland	1296
Power Sky	1279
Predki	0332
Preisner	0132, 0396, 1113, 1366
Premier	0853, 0723, 0292, 1429
Primacom	1111
Primestar	0869
Promax	0455
Proscan	0392, 0566
Proton	1535
QNS	1367, 1404
Quadral	0369
Quali-TV	1955
Quelle	0299, 0607
Radiola	0200
RadioShack	0566, 0775, 0869
Radix	0396, 1113, 1317
RCA	0392, 0566, 1142, 0775, 0855, 0143, 1291, 1392, 1442
Rebox	1214
Redstar	0369
Regal	1251
RFT	0200
Roadstar	0853, 0713
Rollmaster	1413
Rover	0369, 0713
Rownsonic	1567
S-ZWO	1207
SAB	1251
Saba	0820, 0607, 0885

Downloaded From TheatreSystem-Manual.com Manuals

Sabre	0455
Sagem	0820, 1114, 1253, 1690, 1692
Samsung	1377, 1142, 1276, 1108, 1109, 0853, 1017, 1206, 1293, 1442, 1458, 1570, 1609, 1795, 1916
Sanyo	0493, 1219
SAT	0321
Sat Control	1300
Sat Cruiser	1143
Sat Partner	0332, 0335
Sat Team	0713
SAT+	1409
Satcom	0605, 0607
Satec	0713
Satelco	0369, 1232
Satplus	1100
Satstation	1083
Schaub Lorenz	1214
Schneider	1206, 1251
Schwaiger	1111, 0132, 0504, 0605, 0607, 0732, 0885, 1075, 1083, 1317, 1334, 1412, 1457
SCS	0299, 1331
Sedea Electro.	0132, 0125, 1206, 1279, 1283, 1626
Seemann	0396
SEG	0114, 0332, 0369, 0605, 1075, 1251, 1626
Seleco	0364
Septimo	0885, 1375
Serd	1412
Serino	0610
Servimat	1611
ServiSat	0713, 1251
Sharp	0494, 1489, 1513, 1517, 1955
Siemens	0173, 0396, 1334, 1429, 1657
Silva	0299, 0335
Skantin	0713
SKR	0713
SKY	0856, 1856, 0099, 0847, 0887, 1175, 0711, 1656, 1662, 1693, 1848, 1850
Sky Brazil	0856, 0887
SKY Italia	0853, 1693, 1848
Sky XL	1251, 1412
Sky+	1175
Skymaster	1200, 0605, 0713, 1075, 1334, 1409, 1567, 1611
Skymax	0200
Skyplus	1232, 1334, 1412
SkySat	0114, 0605, 0607, 0713
Skyvision	0364, 1334
SL	0132, 0299, 1294, 1672
SM Electronic	1200, 0713, 1409
Smart	0132, 0396, 0713, 1113, 1232, 1404, 1413
Sony	0639, 1639, 0847, 0853, 0292, 0163, 0275, 0282, 0294, 0455, 1524, 1558, 1640
SR	0132
Star	0887
Star Choice	0869
Star Trak	0772, 0869
Starland	0713
Starlite	0200
Starring	0332
Stream	1848
Strong	0853, 0820, 0879, 0132, 0125, 0369, 0713, 1159, 1284, 1300, 1409, 1626, 1765
Sunny	1300
Sunny Sound	0369
Sunsat	0713
Sunstar	0642, 0132, 0369
Supermax	1143, 1283
Supernova	0887
Systec	1334
Tagra	0364
Tantec	0455
Targa	1807
Tatung	0455
TBoston	1659
TCL	1143
Teac	1227, 1251, 1322
Tecatel	1200
Techniland	0364
TechniSat	0114, 0396, 0455, 1099, 1100, 1195, 1197, 1322
Technomate	1283, 1610
Technosat	1143, 1206, 1331
Technosonic	1672
Technotrend	1429
Technowelt	0132, 0607
Techsan	1017
Techwood	0114, 1284, 1626
tekComm	1017
Telasat	0605, 0607
Tele System Elec.	0396, 1251, 1409, 1611, 1801
TeleClub	1367
Teleka	0396, 0607
Telesat	0605, 0607
Telestar	0114, 1099, 1100, 1251, 1334, 1610, 1626
Telesystem	1801
Teletech	0114
Televes	0132, 0455, 1214, 1300, 1334, 1742
Televisa	0887
Telewire	0364, 1232
Tempo	1143
Tensai	0332
Tevion	0713, 1409, 1593, 1622, 1672
Thomson	0392, 0566, 0847, 0853, 0820, 1175, 0292, 0711, 0713, 0607, 0455, 0885, 1046, 1291, 1534, 1543, 1662
Thorn	0455
Tiny	1672
Tioko	0132
Tivo	1142, 1442, 1443, 1444
Tokai	0200
Tonna	0364, 0455, 0713, 1611
Topfield	1206, 1207, 1208, 1545, 1783, 1824
Toshiba	0749, 1749, 0790, 0819, 0455, 0486, 1285, 1446, 1501, 1516, 1530
TPS	0820, 1253
Triad	0321, 0335
Triax	0853, 0200, 0132, 0114, 0396, 0713, 1113, 1227, 1251, 1291, 1296, 1626, 1742
Trio	1075
TT-micro	1429

Downloaded From TheatreSystem-Manual.com Manuals

Turnsat 0713
Twinner..... 0713, 1611, 1742
UEC..... 0879, 1356
UltimateTV..... 1392, 1640
Uniden 0724, 0722, 1521
Unisat 0200, 0132
United 1251
Unitor 0332
Universum 0173, 0114, 0299, 0607, 1099, 1251
US Digital 1535
USDTV 1535
Van Hunen 1161
Variosat 0173
Vega 0369
Ventana 0200
Versatel 1795
Vestel 0114, 1251
VH Sat 0299
Viasat 1682
Victor 0492
Vidtech 0321
ViewSat 1232
Visionic..... 0125, 1279, 1283
VisionNet 1557
Visiosat..... 0114, 0713, 1129, 1413, 1457, 1718, 1742, 1807
Viva..... 0856
Voom..... 0869
VTech 0321, 0818
Wavelength 1232, 1413
Wetekom 0605
Wewa 0455
Wharfedale..... 1284
Winbox 1801
Winersat..... 0332
Wintel 0299, 1161
Wisi..... 0173, 0132, 0299, 0321, 0396, 0455, 0607
World 0332
Worldsat 0114, 1214, 1251, 1543
XMS..... 1075
Xoro 1807
Xrypton 0369
Xsat..... 0847, 0713, 1214, 1323
Xtreme 1300
Yakumo 1413
Yamada 1718
Yes..... 0887
Zehnder 0114, 0321, 0369, 0504, 0818, 1075, 1232, 1251, 1616
Zenith 0856, 1856
Zeta Technology 0200
Zodiac 0396, 1801

CD/DVD

RCA 0522
Sharp 0037
Sony 0878, 1033
Universum 0053

DVD

3D LAB 0503, 0539
4Kus 1158
A-Trend..... 0714
Accurian 1072, 1416
Acoustic Solutions 0730, 0713, 1228, 1242, 1316
Adcom 1094
Advent 1016
AEG..... 0770, 0790, 0788
AFK 1051, 1152
Afreey 0698
Aim..... 0672, 0699, 0778, 0833, 1165, 1177
Airis 0672, 0826, 1005, 1107, 1224, 1321, 1345
Aiwa 0533, 0641
Akai 0770, 0695, 0790, 0690, 0705, 0716, 0766, 0779, 0788, 0884, 0898, 0899, 1089, 1115, 1233
Akashi 0838
AKI 1005
Akira 0699, 1321
Akura 0898, 1051, 1140, 1171, 1233, 1367
Alba..... 0672, 0539, 0717, 0695, 0730, 0699, 0713, 0783, 0884, 1140, 1530, 1610
Albatros..... 1001
Alco..... 0790
Alize 1151
All-Tel 0835, 1451
Allegro..... 0869
Altacom..... 1224
Amisos 0782
Amitech..... 0784, 0770, 0850
Amoi..... 0852
Amoisonic 0835
Amphion Media Works 0872, 1245
Amstrad 0770, 0713, 1151, 1173, 1367, 1407
Amuseer 1351
AMW..... 0872, 1245
Ansonic 0831, 0759, 1316, 1351
Apex Digital 0533, 0672, 0717, 0755, 0794, 0796, 0797, 0830, 1004, 1020, 1056, 1061, 1100, 1126
Aria 0893
Arianet 0818, 0893
Aristona 0539, 0646
Arrgo 1023
Asono 1224
Aspire Digital ... 1168, 1407
Astar 1489
Atacom 1224
Audiologic 0736
Audiosonic 0690, 1265
Audiovox 0717, 0790, 1041, 1071, 1072, 1121, 1122
Audioworld 0790
Autovox 0713
Auvio 0843
Avious 1165
Awa 0730, 0872
Axion 0730, 1071, 1072, 1193
B & K 0655, 0662
Bang & Olufsen 1696
Base 1451
Basic Line..... 0713
Baze 0898, 1165
BBK 0862, 1224
Beep..... 1163
Bel Canto Design 1571
Bellagio..... 1004, 1245
Belson 1086

Downloaded From TheatreSystem-Manual.com Manuals

Best Buy 1089
Black Diamond. 0713, 0766, 0833, 0884
Blaupunkt 0717
Blu:sens 1233, 1321, 1489
Blue Nova Intn . 1321
Blue Parade 0571
Blue Sky..... 0672, 0651, 0695, 0790, 0699, 0713, 0778, 0804, 0843, 1423
Boghe 1004
Boman 0783, 0898, 1005
Bose..... 2023
Brainwave 0770, 1115
Brandt 0503, 0651, 0551
Broksonic 0695, 0868, 1419
Buffalo..... 1882
Bush..... 0672, 0717, 0730, 0831, 1483, 1436, 1419, 1351, 1177, 1165, 1140, 1128, 1051, 0884, 0879, 0833, 0778, 0758, 0723, 0713, 0699, 0690, 0516
Byd:sign..... 0872
C-Tech 0798, 1152
Calif Aud Labs.. 0490
Cambridge Aud 0751, 1109, 1589
Cambge Sndwks 0690
Campomatic Dig. 1051
Cary Audio Des 1477
Cat 0699, 0789, 1421
CAVS..... 1057
CCE..... 0730
Celestial 1020
cello 1730
Centrex 0672, 1004
Centrios..... 1577
Centrum..... 0713, 0779, 0789, 1005, 1227
CGV..... 0751, 1115
Changhong 0627, 1061
Cinea 0831, 0841
Cinego 1399
Cineral 0730
Cinetec 0713, 0872
cineULTRA 0699
CineVision..... 0876, 0833, 0869, 1483
Citizen 1003, 0695, 1277
Clairtone 0571
Classic..... 0730, 1730
Clatronic 0672, 0675, 0788, 0818, 1165, 1177, 1233
Clayton 0713
Coby..... 0730, 0778, 0852, 1077, 1086, 1107, 1165, 1177, 1321, 1351
Codex 1233
Commax 1321
Compacks..... 0826, 1107, 1265
Conia 0672, 0516, 0835, 0852, 1321
Contel 0788
Continental Ed. 0831, 0872
Craig 0831
Creative 0503, 0539
CrossWood 1446
Crown 0770, 0690, 0713, 0769, 1115
Crypto 1228
Curtis Mathes... 1087
Cybercom..... 0831
CyberHome 0714, 0816, 0874, 1017, 1023, 1024, 1117, 1129, 1173, 1502, 1537
Cydectin..... 1074
Cytron 0651, 0705, 0716, 1347
D-Link 1881
D-Vision 1115, 1367
Daenyx 0872
Daewoo 0490, 0784, 0770, 1483, 1443, 1441, 1436, 1242, 1234, 1172, 1169, 1072, 0872, 0869, 0833, 0714, 0705
Dalton 1036, 1107
Dansai 0770, 0783, 1115
Dantax 0539, 0790, 0713, 0723, 1089
Daytek 0872, 1005
Dayton 0872
DCE..... 0831
DEC..... 0778, 0818
Decca 0770, 1115
Denon 0490, 0634, 1282, 1634
Denver 0672, 0699, 0778, 0788, 0898, 1056, 1104, 1107, 1165, 1177, 1265, 1316, 1321
Denzel 0665
Desay 0800, 0843, 1407, 1455
Dgtec 0672
Diamond 0651, 0768, 0790, 0751, 0778
Diamond Vision 1316, 1609, 1610
Dick Smith Elec 0833, 1152, 1483, 1730
Digihome..... 0713
DigiLogic 0713
digiRED 0717
Digital i 0893
DigitalMax 1738
Digitor..... 0651, 0690, 0833, 1005, 1423
Digitrex..... 0672, 1004, 1056, 1100
Digix Media 0826
DiK 0831
Dinamic 0788
Disney 0831, 0675, 1270
DiViDo 0705
DK Digital 0831
DMTech 0783, 1072
Dragon 0831
DreamX 1151
DSE 0833, 1152, 1483, 1730
DTS 0799
Dual..... 0651, 0730, 0831, 0790, 0665, 0675, 0713, 0779, 0783, 1023, 1068, 1085, 1436
Durabrand 1003, 0831, 0713, 1023, 1127, 1502
DVD2000..... 0521
DVX 0768
E:max 1233, 1321
EagleTec..... 0714
eBench 1152
ECC..... 0730
Eclipse..... 0723, 0751
Electrohome..... 1003, 0893
Elfunk 0713, 0850, 0884
Elin 0770
Elite 1152
Ellion 0850, 1421
Elta..... 0672, 0770, 0690, 0788, 0850, 1051,

Downloaded From TheatreSystem-Manual.com Manuals

	1115, 1151, 1173, 1233
Eltax	0766, 1233, 1321
Emerson	0591, 0675, 0705, 0821, 1268
Encore	0698
ENTERprise	0591
Entivo	0503, 0539
Enzer	0784, 0770, 0766, 1228
ESA	0821, 1268, 1443
EuroLine	0675, 0788, 1115, 1233, 1351
Fenner	0651
Ferguson	0651, 0695, 0713, 0884, 0898, 1730
Finlux	0672, 0591, 0741, 0770, 0751, 0783, 1165
Fintec	1169
Firstline	0651, 0713, 0799, 0843, 0869, 1530
Fisher	0670
Funai	0695, 0675, 1268, 1334
Fusion	0862
Gateway	1073, 1077, 1158, 1194
GE	0522, 0815, 0717
General Electric	0717
Germatic	1051
Global Link	1224
Global Solutions	0768
Global Sphere	1152
Go Video	0573, 0744, 0717, 0741, 1730, 1483, 1443, 1304, 1158, 1144, 1099, 1075, 1044, 0869, 0833, 0783, 0715
Go Vision	1071, 1072
GoldStar	0591, 0741, 0801, 0869
Goodmans	0651, 0730, 0790, 0690, 0713, 0723, 0783, 0833, 0879, 1004, 1140, 1177, 1316, 1423, 1530, 1730
GP Audio	1140
GPX	0741, 0699, 0769
Gradiente	0490, 0651
Graetz	0665
Gran Prix	0831, 0898
Grandin	0713, 0716, 1173, 1233
Greenhill	0717
Grundig	0539, 0651, 0551, 0695, 0790, 0670, 0705, 0713, 0775, 1004, 1036, 1128, 1177, 1436, 1730
Grunkel	0770, 0831, 0790, 1316
GVG	1169
H & B	0713, 0818, 0841, 0850, 1233, 1421
Haaz	0751, 1152
Haier	0843
Hanseatic	0741, 0790, 0783
Harman/Kardon	0582, 0702
HCM	0788
HDT	0705
HE	0730, 1163
Helios	2080
Henss	0713
Himage	1089
HiMAX	0843
Hitachi	0573, 0664, 0695, 0665, 0713, 0857, 1247, 1664
Hiteker	0672
Hoeher	0651, 0831, 0713, 0826, 1004, 1224
Home Elec.	0770, 0730
Home Tech Indus.	1107, 1224
Hoyo	0665
Humax	0646, 1588
Hyundai	0766, 0783, 0850, 1061, 1228
I-O Data	1405
iLo	1348, 1472
Ingelen	0788
Ingersol	1023
Initial	0839, 0717, 1472
Inno Hit	0713
Innovative Tech.	1542
Insignia	1013, 1268
Integra	0571, 0627, 1634
Irradio	0869, 1115, 1224, 1233
IRT	0783, 1489
ISP	0695
Jamo	1036
Jaton	0665, 1078
Jay-tech	1265
JBL	0702
JDB	0730
JDV	1367
Jeken	0699
Jensen	1016
Jeutech	0766
JMB	0695
JNC	0672
JSI	1423
JVC	0503, 0539, 0558, 0623, 0867, 1164, 1241, 1275, 1597, 1602
jWin	1049, 1051
Kansai	1107
Kansas Tech.	1233, 1530
Karcher	0783
Kawasaki	0790
Kendo	0672, 0831, 0699, 0713
Kennex	0770, 0713, 0898
Kenwood	0490, 0534, 0682, 0737, 1063
Kiiro	0770
King DHome	0799
Kingavon	0818
Kiss	0665, 0841, 1523
KLH	0815, 0717, 0790, 1020, 1149, 1261
Kloss	0533
Koda	1230
Konka	0711, 0719, 0720, 0721
Koss	0651, 0769, 0896, 1061, 1423
Kreisen	1421
KXD	0857, 1321
Landel	0826
Lasonic	0627, 0798, 0789, 1173
Lawson	0768, 0716
Lecson	1533
Leiker	0872
Lenco	0651, 0770, 0699, 0713, 0778, 1165, 1177
Lenoir	1228
Lenoxx	0690, 0838, 1127
Lexia	0768, 0699
LG	0591, 0741, 0790, 0801, 0869, 1526
Lifetec	0651, 0831, 1347
Limit	0768, 0716, 1104
LiteOn	1058, 1158, 1416, 1440, 1656, 1738

Downloaded From TheatreSystem-Manual.com Manuals

Lodos	0713
Loewe	0539, 0741, 0511, 0885
Logik	0713, 0884
Logix	0705, 0783
Luker	1367
Lumatron	0741, 0695, 0705, 0713, 0833, 1115, 1321
Lunatron	0741
Luxman	0573
Luxor	0713, 1004, 1730
Magnasonic	0651, 0675, 0769
Magnavox	0503, 0539, 0646, 0675, 0713, 0821, 0885, 1140, 1177, 1268, 1472, 1506
Magnex	0723, 1165, 1489
Magnum	1436
Majestic	1107, 1345
Malata	0782, 1159
Manhattan	0705, 0713
Marantz	0503, 0539, 0675, 1627
Mark	0713
Marquant	0770
Matsui	0672, 0651, 0695, 0713, 0884, 1004, 1316, 1730
Maxdorf	0788
Maxent	1347
Maxim	0713, 0872, 1242, 1367
Maya	1345
MBO	0730, 0690, 1730
McIntosh	1533, 1273
MDS	0713, 0778
Mecotek	0770
Medion	0651, 0630, 0831, 0652, 0716, 0758, 0783, 0879, 1006, 1107, 1165, 1270, 1345, 1347, 1423
MEI	0790
Memorex	0695, 0831, 0690, 1270
Metronic	0690
Metz	0525, 0571, 0713
MiCO	0723, 0751, 1223
Micromedia	0503, 0539
Micromega	0539, 1005
Microsoft	0522, 1708, 2083
Microstar	0831
Minato	0752
Minax	0713
Minerva	0705
Minoka	0770, 1115
Minowa	1165
Mintek	0839, 0717, 1472
Mirror	0752, 0879
Mitsubishi	1521, 0521, 0713, 1403
Mizuda	0770, 0818, 0857, 1451
Momitsu	1082
Monyka	0665
MPX	0843
MTlogic	1265
Mustek	0730, 1730
Mx Onda	0651, 0751, 1223
Myryad	0894
Mystral	0831
NAD	0741, 0692
Naiko	0770, 1004, 1367
Nakamichi	1222
Narita	1367
NEC	0741, 0692, 0785, 0869, 1404
Nesa	0717, 1603
Neufunk	0665
NeuNeo	0509, 1454
Nevir	0770, 0831, 1197
Next Base	0826
NexxTech	1402
NFREN	0826
Nikenny	1089
Nintaus	1051
Norcent	1003, 0719, 0872, 1107, 1265, 1457
Nordmende	0831, 1316
Noriko	0752
Nowa	0843
Nu-Tec	0516, 1228
Okano	0752
Olidata	0672
Omni	0690, 0698, 0778, 0782, 0833, 0838, 0862, 1104
Onix	0838
Onkyo	0503, 0627, 0792, 1417, 1418, 1612, 1627
Oopla	1158
Oppo	1224, 1525
Optim	0843
Optimus	0525, 0571
OptoMedia Elec.	0896
Orava	0818
Orbit	0872
Orion	0695, 1128, 1233, 1419
Oritron	0651
Ormond	0713
Otic	0826, 1455
P&B	0818, 1451
Pacific	0695, 0831, 0768, 0790, 0713, 0759, 0804
Packard Bell	0831
Palladium	0695, 0713, 0779
Palsonic	0672, 0835, 0852, 1056, 1321
Panasonic	0503, 0490, 0571, 0632, 0703, 1010, 1011, 1282, 1362, 1462, 1490, 1579, 1762, 1641
Panda	0717, 0789
Paramount Picts	0779
peeKTon	0898, 1224
Philco	0790, 0690, 0788, 0862
Philips	0503, 0539, 0646, 0675, 0854, 0885, 1158, 1260, 1267, 1340, 1354, 1506, 1755, 2056
Philo	1345
Phonotrend	0699, 1165, 1177
PianoDisc	1024
Pioneer	0490, 0525, 0571, 0142, 0631, 0632, 0638, 1460, 1531, 1571, 1900
Playgo	1265
Plu2	0850
Pointer	0784
Polaroid	1020, 1061, 1086, 1245, 1316, 1478, 1480, 1482
Polk Audio	0539
Portland	0770
Powerpoint	0758, 0872, 1005
Presidian	0675, 1072, 1738
Prima	0766, 1016, 1228
Prima Elec	0766
Primare	1467
Princeton	0674
Prinz	0831

DVD

Downloaded From TheatreSystem-Manual.com Manuals

Prism	0831, 0705, 1089
Pro2	1107, 1345
ProCaster	1004
Proceed	0672
Proline	0672, 0651, 0710, 0833, 1004, 1068, 1483
Proscan	0522
Proson	0713
Prosonic	0699, 0752, 1169, 1441
ProVision	0730, 0699, 0778, 1107, 1163, 1321
Pye	0539, 0646
QONIX	1051, 1177
Qwestar	0651
Radionette	0741, 0869
RadioShack	0571
Raite	0665
RCA	0522, 0571, 0717, 0790, 0769, 0822, 1013, 1022, 1132, 1193, 1769
Realistic	0571
REALmagic	0674
REC	0490, 0766
Recco	0698
Redstar	1003, 0770, 0759, 0763, 0788, 0898, 1107, 1345
Relisys	1347
Reoc	0768, 0752
Revoy	0699, 0841
Rex	0838
Richmond	1233
Rio	0869
RJTech	1360
Roadstar	0672, 0730, 0690, 0699, 0713, 0818, 0833, 0879, 0898, 1051, 1177, 1227, 1446
Rocksonic	0789
Ronin	0710, 0872
Rotel	0558, 0623, 1178
Rowa	0717, 0516, 0759, 0823, 0872, 1004
Rownsonic	0789
S&V	1165
Saba	0651, 0551, 0769
Sabaki	0798
Saivod	0831, 0759, 1367
Salora	0741, 1446
Sampo	0698, 0752, 1321, 1347, 1501
Samsung	0490, 0573, 0744, 0199, 0820, 0899, 1044, 1075, 1635
Sansui	0784, 0695, 0768, 0716, 0751, 0763, 1051, 1228, 1230, 1316
Santosh	1115
Sanyo	0695, 0670, 0675, 0713, 0873, 1228, 1334
Scan	0705, 0835, 0850
ScanMagic	0730, 1730
Schaub Lorenz	0770, 0788, 1115, 1151, 1165
Schneider	0539, 0646, 0651, 0831, 0790, 0705, 0713, 0779, 0783, 0788, 0804, 0869, 1367
Schwaiger	0752
Scientific Labs	0768
Scott	0672, 0651, 1005, 1036, 1233, 1423
Seeltech	1224, 1451
SEG	0798, 0665, 0713, 0763, 0872, 0884, 1173, 1483, 1530
Semp	0503
Sensory Science	1158
Shanghai	0672
Sharp	0630, 0675, 0713, 0752, 1256, 1419, 1642
Sharper Image	1117
Sherwood	0717, 0741, 0770, 0633, 1043, 1077
Shinco	0717, 1472
Shinsonic	0533, 0839
Siemssen	1382
Sigma Designs	0674
Sigmatek	1005, 1224
Siltex	1224
Silva	0788, 0898
Silva Schneider	0831, 0898
SilverCrest	1152
Simaudio	0885
Singer	0768, 0690, 0716, 0751
Sinudyne	1316
Sistemas	0672
Skantic	0539, 1003, 0713
Skymaster	0730, 0768
Skysonic	0766
Skyworth	0766, 0898
Sliding	1115
Slim Art	0784
SM Electronic	0730, 0768, 0690, 1152
Smart	0705, 0713
Sonai	0755
Sonashi	0831, 0716
Sonic Blue	0573, 0715, 0783, 0869, 1099
Sony	0533, 1533, 0864, 0573, 0630, 1017, 1033, 1069, 1070, 1431, 1432, 1433, 1516, 1536, 1548, 1633
Sound Color	1233
Sound Mobile	1298
Soundmaster	0768
Soundmax	0768
Soundwave	0783
Sova	1122
Spectra	0872
Standard	0651, 0831, 0768, 0788, 0898
Star Clusters	1152, 1227
Starlogic	1005
Starmedia	0818, 1005, 1224
Stevison	1367
Strong	0713
Sungale	1074, 1532
Sunkai	0770, 0850
Sunstech	0831, 1072
Sunwood	0788, 0898
Superscan	0821
Supervision	0768, 1152
Supratech	0893
SVA	0672, 0717, 0752, 0860, 1105
Sylvania	0630, 0675, 0821, 1268
Symphonic	0675, 0821, 1268, 1334
Synn	0768
TAG McLaren	0894
Tandberg	0713
Tangent	1321
Targa	1227
Tatung	0770
Tchibo	0741

Downloaded From TheatreSystem-Manual.com Manuals

TCM	0741, 0790
Teac	0571, 0717, 0741, 0768, 0790, 1483, 1227, 1197, 1165, 1006, 0833, 0809, 0759, 0758, 0692, 0675, 0516
Tec	0898
Technica	1367
Technics	0490, 0703
Technika	0770, 0831, 1115, 1165, 1489
Technisson	1115
Technosonic	0730, 1051, 1115
Techwood	0692, 0713, 1530
Tedelex	0768, 0690, 1004, 1228
Telefunken	0790, 0758, 0789, 0833, 1483
Teletech	0768, 0713
Tensai	0651, 0770, 0690
Terapin	1031
Tevion	0651, 0798, 0768, 0652, 0833, 0898, 1036, 1227, 1347, 1382, 1483, 1730
Theta Digital	0571
Thomson	0522, 0551, 0511
Tiny	1489
Tivo	1503, 1588
Tokai	0784, 0790, 0665, 0698, 0788, 0898
Tokaido	0698
Tokiwa	0716
Tom-Tec	0789
Top Suxess	1224
Toshiba	0503, 0573, 0539, 0695, 1045, 1154, 1503, 1510, 1588, 1769
Trans Continens	0826
TRANS-conts	0831, 0826, 0872, 1165, 1321, 1327
Transonic	0730, 1165
Tredex	0799, 0800, 0803, 0804, 0843
TruVision	0857, 1451
TSM	1224
TYT	0705
Umax	0690, 1151
Unimax	0770
United	0695, 0730, 1489, 1446, 1367, 1351, 1228, 1173, 1165, 1152, 1115, 1072, 0884, 0826, 0788, 0713, 0699, 0675
Universum	0591, 0741, 0790, 0713, 0779, 0869, 1227, 1530
Uptek	0763
upXus	1345
Urban Concepts	0503, 0539
US Logic	0839
V	1064, 1126, 1226
Valor	1298
Venturer	0790
Vestel	0713, 0884, 1530
Vialta	1509
Victor	1241, 1597
Vieta	0705, 1265
Viewmaster	0862, 1224
Vizio	1064, 1126, 1226
Vocopro	1027, 1360
Voxson	0730, 0831, 0690
Vtrek	1228
Waitec	1151, 1224, 1233
Walkvision	0717
Waltham	1530
Welkin	0831
Wellington	0713
Weltstar	0713
Wesder	0699
Wharfedale	0790, 0698, 0751, 0752
Wilson	0831, 1233
Windsor	0713
Windy Sam	0573
WIZE	1115
Woxter	1005, 1151, 1224
Xbox	0522, 1708, 2083
Xenius	0790
XLogic	0768, 1152, 1228
XMS	0770, 0788
Xoro	1173, 1183
Xwave	1001
Yakumo	0652, 1004, 1056
Yamada	0652, 0872, 1004, 1056, 1151, 1158, 1416, 1489
Yamaha	0490, 0539, 0646, 0545, 1282, 1354
Yamakawa	0665, 0710, 0872, 1104, 1489
Yukai	0730, 1730
Zenith	0503, 0591, 0741, 0869
Zennox	1265
Zeus	0784
Zoece	1265

VCR

A-Mark	0037, 0240, 0000, 0278, 0046
ABS	1972
Accent	0072
Admiral	0060, 0048, 0039, 0047, 0104, 0121, 0209, 0020, 0062, 0065, 0479
Adventura	0037, 0240, 0000
Adyson	0072
Aiko	0278
Aim	0278, 0348, 0642, 0020
Aiwa	0037, 0032, 0000, 0209, 0041, 0348, 0307, 0352, 0124, 0479, 0742, 1137, 1284, 1291, 1332, 1336
Akai	0037, 0240, 0041, 0348, 0642, 0352, 0315, 0020, 0053, 0061, 0175, 0242
Akiba	0072
Akitan	0295
Akura	0041, 0072, 0271
Alba	0081, 0000, 0209, 0072, 0278, 0348, 0352, 0315, 0020, 0295
Alienware	1972
Allegro	0039, 1137
Allorgan	0240
Allstar	0081
Ambassador	0020
America Action	0278
American High	0035, 0081
Amoisonic	0479
Amstrad	0000, 0072, 0278
Anam	0162, 0037, 0240, 0278, 0579, 1037
Anam National	0162, 1562, 0454, 0579, 1162
Anitech	0072
Ansonic	0000

Downloaded From TheatreSystem-Manual.com Manuals

Arion	1787
Aristona	0081
ASA	0037, 0081
Asha	0240
Astra	0035, 0240, 0051
Asuka	0037, 0081, 0000, 0072, 0038
Audio-Technica	0058
Audiolab	0081
Audiosonic	0278
Audioton	0020
Audiovox	0037, 0278, 0038, 0054
AVA Tech.	0615
Avis	0000, 0072
AVP	0000, 0352
Awa	0037, 0043, 0278, 0642, 0075, 0579
Baird	0000, 0104, 0041, 0278, 0046
Basic Line	0104, 0072, 0278, 0020, 0046
Beaumark	0240
Beko	0104
Bell & Howell	0035, 0048, 0039, 0000, 0104, 0046, 0479
Bestar	0278, 0020
Black Diamond.	0642
Black Panther	0278
Blaupunkt	0162, 0081, 0034, 0227, 0513
Blue Sky	0037, 0209, 0072, 0278, 0348, 0642, 0352, 0742, 1137
Bondstec	0072, 0020
BPL	0046
Brandt	0041, 0320
Brandt Elec.	0041
Brinkmann	0209, 0348
Broksonic	0184, 0121, 0209, 0002, 0348, 0208, 0211, 0295, 0361, 0479, 1479, 1815
Bush	0081, 0000, 0209, 0072, 0278, 0348, 0642, 0352, 0315, 0742
Calix	0037
Candle	0037, 0038
Canon	0035, 0034
Capehart	0002, 0020, 0062
Carena	0081, 0209
Carrefour	0045
Carrera	0240
Carver	0035, 0081
Casio	0000
Cathay	0278
Catron	0020
CCE	0072, 0278
Centrum	0593
CGE	0000, 0041
Changhong	0048, 0081
Cimline	0209, 0072
Cineral	0278
CineVision	1137
Citizen	0035, 0037, 0240, 0000, 0209, 0278, 0036, 0479, 1278
Classic	0037
Clatronic	0000, 0072, 0020, 1593
Colortyme	0060, 0035, 0045, 0278
Colt	0000, 0072
Combitech	0352
Condor	0278, 0020
Craig	0037, 0047, 0240, 0072, 0271
Criterion	0000, 0072
Crosley	0035, 0081, 0000, 0149, 0110
Crown	0037, 0072, 0278, 0020, 0271
Curtis Mathes	0060, 0035, 0162, 0240, 0000, 0041, 0278, 0432, 0277, 0454, 0643, 0760, 1035
Cybernex	0240, 0051
CyberPower	1972
Cyrus	0081
Daewoo	0037, 0045, 0104, 0209, 0278, 0642, 0352, 0020, 0046, 0210, 0212, 0368, 0561, 0844, 1137, 1278
Dansai	0072, 0278
Dantax	0352
Daytron	0037, 0278, 0020
De Graaf	0048, 0081, 0042, 0104, 0046
Decca	0081, 0000, 0067, 0209, 0041, 0352, 0008
Degraff	0048, 0081, 0042, 0104
Deitron	0278
Dell	1972
Denko	0072
Denon	0081, 0042
Derwent	0041
Diamant	0037
Diamond	0348
Dick Smith Elec	0642, 0579
Digitor	0642, 0579
DirecTV	0739, 2033
Domland	0209
DSE	0642, 0579
Dual	0081, 0000, 0041, 0278, 0348
Dumont	0081, 0000, 0104, 0105
Durabrand	0039, 0038, 0642, 0593
Dynatech	0240, 0000
Elbe	0278, 0038
Elcatech	0072
Electrohome	0060, 0037, 0240, 0000, 0043, 0209, 0061
Electrophonic	0037
Elin	0240, 0051
Elsay	0072
Elta	0072, 0278
Emerald	0184, 0121, 0211
Emerex	0032
Emerson	0035, 0037, 0184, 0039, 0240, 0045, 0000, 0121, 0043, 0209, 0072, 0002, 0278, 0348, 0561, 0510, 0593, 0479, 0378, 1278, 1479, 0361, 1593, 0343, 0295, 0294, 0212, 0211, 0208, 0202, 0088, 0068, 0061, 0036
ESA	1137
ESC	0240, 0278, 0020
EuroLine	1593
Europhon	0020
Fenner	0020
Ferguson	0000, 0041, 0278, 0348, 0320, 0053
Fidelity	0240, 0000, 0072, 0352, 0432
Finlandia	0037, 0048, 0081, 0000, 0042, 0104,

Downloaded From TheatreSystem-Manual.com Manuals

	0043, 0384, 0046, 0110
Finlux	0081, 0000, 0042, 0104, 0105
Firstline	0037, 0045, 0042, 0043, 0209, 0072, 0278, 0348, 0088, 1137
Fisher	0039, 0047, 0000, 0104, 0020, 0046, 0054, 0066
Flint	0209, 0348
Frontech	0072, 0020
Fuji	0035, 0033
Fujitsu	0037, 0045, 0000, 0366
Fujitsu General	0037
Funai	0037, 0000, 0072, 0278, 0294, 0593, 1333, 1593
Galaxi	0000
Galaxis	0278
Garrard	0000
Gateway	1972
GBC	0020
GE	0060, 0035, 0048, 0240, 0000, 0149, 0320, 0065, 0077, 0202, 0277, 0760, 0761, 0807, 1035, 1060
GEC	0081
Gemini	0060
General	0045, 0020, 0366
General Technic	0348
Genexxa	0037, 0000, 0104, 0278
Go Video	0240, 0432, 0232, 0526, 0614, 0643, 1137
GoldHand	0072
GoldStar	0035, 0037, 0039, 0000, 0209, 0278, 0038, 0018, 0054, 0225, 1137, 1237
Goodmans	0037, 0081, 0240, 0000, 0209, 0072, 0278, 0348, 0642, 0352, 0020, 0062, 0343, 0579, 0742
GPX	0037
Gradiente	0000, 0008, 1137
Graetz	0240, 0104, 0041
Granada	0035, 0037, 0048, 0081, 0240, 0000, 0042, 0104, 0011, 0046
Grandin	0037, 0000, 0209, 0072, 0278, 0020, 0742
Grundig	0081, 0072, 0348, 0320, 0352, 0034, 0207, 0347, 0378, 0742
Haaz	0348
Hanimex	0352, 0295
Hanseatic	0037, 0081, 0209, 0038
Hantor	0020
Haojie	0240
Harley Davidson	0000
Harman/Kardon	0081, 0038, 0075
Harvard	0072, 0068
Harwood	0072, 0068
HCM	0072
Headquarter	0046
Hewlett Packard	1972
HI-Q	0035, 0047, 0000
Hinari	0240, 0209, 0041, 0072, 0278, 0352, 0088, 0208, 0343
Hisawa	0209, 0352
Hischito	0045
Hitachi	0035, 0037, 0081, 0240, 0045, 0000, 0042, 0041, 0384, 1326, 1286, 1037, 0593, 0544, 0105, 0089, 0082, 0065, 0046
Hoeher	0278, 0642
Hornyphon	0081
Howard Comps	1972
HP	1972
Hughes Net Sys	0042, 0739
Humax	0739, 1711, 1845, 1853
Hush	1972
Hypson	0037, 0000, 0209, 0072, 0278, 0352
Hytek	0047, 0000, 0072, 0036
iBUYPOWER	1972
Imperial	0000
Ingersol	0240, 0209
Inno Hit	0072, 0020
Interbuy	0037, 0072
Interfunk	0081, 0104
Internal	0278
International	0037, 0278, 0642
Intervision	0037, 0000, 0209, 0278, 0348
Irradio	0037, 0081, 0072, 1137
ITT	0240, 0104, 0041, 0384, 0046, 0378
ITT Nokia	0240, 0104, 0041
ITV	0037, 0278, 0020
Janeil	0240
JBL	0278
Jensen	0067, 0041
JMB	0209, 0348, 0352, 0742
Joyce	0000
JVC	0184, 0081, 0045, 0067, 0041, 0384, 1707, 1329, 1299, 1283, 1279, 1162, 0486, 0366, 0207, 0061, 0058, 0008
Kaisui	0072
Kambrook	0037
Karcher	0081, 0278, 0642
Kathrein	1802, 1868, 1869, 1870
KEC	0037, 0278
Keen	0693
Kendo	0037, 0209, 0072, 0278, 0348, 0642, 0315, 0053
Kenwood	0067, 0041, 0038, 0384, 0046
KIC	0000
Kimari	0047
Kioto	0348
KLH	0072
Kneissel	0037, 0209, 0278, 0348, 0352
Kodak	0035, 0037
Kolin	0043, 0041
Kolster	0209
Korpel	0072
KTV	0000
Kuba	0047
Kuba Electronic	0047
Kyoto	0072
Lenco	0278
Leyco	0072
LG	0037, 0240, 0045, 0000, 0042, 0209, 0278, 0038, 0051,

Downloaded From TheatreSystem-Manual.com Manuals

	0053, 0225, 1037, 1137, 1237
Lifetec	0209, 0348
Linksys	1972
Lloyd's	0240, 0000, 0072, 0038, 0036, 0208
Loewe	1062, 0162, 0037, 0081, 1562, 0105, 0454, 1262
Logik	0240, 0000, 0209, 0072, 0011
Luker	0579
Lumatron	0278, 0593, 1137
Lunatron	1137
Lux May	0072
Luxor	0048, 0047, 0104, 0043, 0072, 0315, 0046, 0062
LXI	0037, 0000, 0042, 0067, 0054
M Electronic	0037, 0240, 0000, 0038
Magnadyne	0081, 0212
Magnasonic	0037, 0240, 0000, 0072, 0278, 0020, 0082, 0593, 1278
Magnavox	0035, 0037, 0048, 0039, 0081, 0240, 0000, 0149, 0642, 1781, 1593, 0618, 0593, 0563, 0110, 0054, 0011
Magnin	0240
Magnum	0642
Manesth	0081, 0045, 0209, 0072
Marantz	0035, 0081, 0209, 0038, 0062, 0295, 1381
Mark	0000, 0278, 0020
Marta	0037
Mastec	0642
Master's	0278
Matsui	0037, 0240, 0209, 0278, 0348, 0352, 0036, 0088, 0208, 0295, 0742
Matsushita	0035, 0162, 0081, 0227, 0367, 0454, 1162
Media Center PC	1972
Mediator	0081
Medion	0209, 0348, 0642, 0352
MEI	0035
Memorex	0035, 0162, 0037, 0048, 0039, 0047, 0240, 0000, 0104, 0209, 0072, 0278, 0348, 0307, 0569, 1262, 1237, 1162, 1048, 1037, 0579, 0479, 0454, 0046, 0062, 0054
Memphis	0072
Mercury	0020
Metronic	0081
Metz	1062, 0162, 0037, 0081, 1562, 0227, 0347, 0454, 0836, 1162, 1262
MGA	0060, 0240, 0043, 0061
MGN Tech.	0240
Micormay	0348
Micromaxx	0209
Microsoft	1972
Midland	0240, 0051
Migros	0000
Mind	1972
Minolta	0042, 0105
Mitsubishi	0060, 0048, 0047, 0081, 0000, 0042, 0067, 0043, 0041, 0642, 1343, 0807, 0443, 0242, 0214, 0173, 0075, 0061
Motorola	0035, 0048
Movie Walker	0072
MTC	0240, 0000, 0072
MTX	0000
Multitec	0037
Multitech	0039, 0000, 0072, 0020
Murphy	0000
Myryad	0081
NAD	0240, 0104, 0058
Naiko	0348, 0642
NAP	0039
Nebula Elec.	0033
NEC	0035, 0037, 0048, 0104, 0067, 0041, 0278, 0038, 0008, 0082, 0370, 1137, 1287, 1288
Neckermann	0081, 0041, 0208
Nesco	0000, 0072
Neufunk	0209
New Tech	0072
Newave	0037
Nikkai	0072, 0278, 0020
Nikko	0037, 0278
Nikkodo	0037, 0278
Nikon	0011, 0034
Nishi	0240
Niveus Media	1972
Noblex	0240
Nokia	0048, 0081, 0240, 0042, 0104, 0041, 0278, 0315, 0036, 0046, 0378
Nordmende	0067, 0041, 0320, 0384, 0207
Northgate	1972
Nu-Tec	0209
Oceanic	0048, 0081, 0000, 0104, 0041, 0046
Okano	0209, 0072, 0278, 0348, 0315
Olympus	0035, 0162, 0104
Onimax	0642
Onkyo	0222
Optimus	1062, 0035, 0162, 0037, 0048, 0047, 0240, 0000, 0104, 0432, 0062, 0058, 0054, 0454, 0593, 1048, 1162, 1262
Optonica	0062
Orbit	0072
Orion	0184, 0240, 0000, 0104, 0121, 0209, 0002, 0278, 0348, 0352, 1815, 1479, 0742, 0479, 0343, 0295, 0294, 0211, 0208, 0088, 0036
Orson	0000
Osaki	0037, 0000, 0072
Osume	0072
Otake	0209
Otto Versand	0081
Pace	0352
Pacific	0000, 0348, 0642, 0742
Packard Bell	1972
Palladium	0037, 0209, 0041, 0072, 0348
Palsonic	0000, 0072, 0642
Panama	0035
Panasonic	1062, 0035, 0162, 0000, 1562, 1807, 1393, 1317, 1308, 1293, 1292, 1262, 1244, 1162, 1035, 0836, 0616, 0615,

Downloaded From TheatreSystem-Manual.com Manuals

	0614, 0513, 0454, 0378, 0367, 0246, 227, 0225, 0077, 0051, 0020
Pathe Cinema ..	0043, 0036
Pathe Marconi..	0041
Penney	0035, 0162, 0037, 0047, 0081, 0240, 0000, 0042, 0067, 0038, 0054, 0077, 1035, 1237
Pentax	0042, 0065, 0105
Perdio	0000, 0209
Philco	0035, 0081, 0000, 0209, 0072, 0038, 0110, 0479, 0561
Philips	0035, 0162, 0048, 0081, 0045, 0000, 0209, 0384, 0110, 0062, 0034, 0563, 0593, 0616, 0618, 0739, 1081, 1181, 1381
Phoenix	0278
Phonola.....	0081
Pilot	0037
Pioneer.....	0162, 0081, 0042, 0067, 0058, 1337, 1388, 1390
Polk Audio.....	0081
Portland	0278, 0020
Precision	0058
Presidian	1593
Prinz	0000, 0088
Profitronic.....	0081, 0240
Proline.....	0000, 0278, 0642, 0320, 0615
Proscan.....	0060, 0202, 0760, 0761, 1060
Prosco	0278, 0844
Prosonic.....	0209, 0278
Protec	0000, 0072
Protech.....	0081, 0072
ProVision	0278
Pulsar	0039, 0240, 0278, 0051
Pulser	0240, 0051
Pye	0081, 0000
Qisheng	0060
Quarter	0046
Quartz	0035, 0047, 0046
Quasar	0035, 0162, 0002, 0278, 0077, 0454, 1035, 1162
Quelle	0081, 0208
Questar.....	0020
Radialva.....	0037, 0048, 0081, 0072
Radiola	0081
Radionette.....	0037, 1137
RadioShack.....	0035, 0162, 0037, 0048, 0047, 0240, 0000, 0104, 0046, 0062, 0066, 1037, 1162
Radix	0037
Randex	0037
Rank	0041
Rank Arena.....	0041
RCA	0060, 0035, 0048, 0240, 0045, 0000, 0042, 0149, 0320, 0065, 0077, 0105, 0058, 0202, 0211, 0054, 0277, 0760, 0761, 0807, 0880, 1035, 1060
Realistic	0035, 0162, 0037, 0048, 0047, 0240, 0000, 0104, 0121, 0278, 0046, 0062, 0065, 0066, 1162
Reoc.....	0348
ReplayTV	0614, 0616
Rex.....	0041, 0384
RFT	0072, 0020
Ricavision	1972
Ricoh	0034
Rio.....	1137
Roadstar	0037, 0081, 0240, 0072, 0278, 0038, 0742
Royal	0072
Runco	0039
Saba.....	0041, 0278, 0320, 0384, 0062, 0207
Saisho	0209, 0348, 0036, 0088, 0208
Salora	0104, 0043, 0046, 0075, 0443
Sampo	0037, 0048
Samsung.....	0060, 0240, 0045, 0000, 0038, 0432, 0051, 0053, 0077, 0210, 0212, 0739, 0760, 1014
Samtron	0240, 0643
Samurai.....	0020
Sanky	0048, 0039
Sansei	0048
Sansui	0240, 0000, 0067, 0209, 0041, 0072, 0002, 0348, 0082, 0271, 0479, 1479
Sanyo	0048, 0047, 0240, 0000, 0104, 0067, 0209, 0348, 0046, 0159, 0368, 0369, 0479, 1137, 1330, 1331
Saville	0240, 0278, 0352
SBR.....	0081
ScanSonic	0240
Schaub Lorenz.	0000, 0104, 0041, 0348, 0315
Schneider	0037, 0081, 0240, 0000, 0042, 0072, 0278, 0348, 0642, 0352, 0110, 1137
Scientific Atlanta	0008
Scott	0184, 0045, 0121, 0043, 0036, 0208, 0210, 0211, 0212, 0593
Sears	0060, 0035, 0162, 0037, 0048, 0039, 0047, 0033, 0045, 0000, 0042, 0104, 0067, 0043, 0209, 0041, 0072, 1237, 0105, 0066, 0065, 0011, 0058, 0054, 0018, 0034, 0046, 0036
Seaway	0278
SEG.....	0081, 0240, 0072, 0278, 0642, 0561
SEI.....	0081
Sei-Sinudyne....	0081
Seleco	0037, 0041, 0384, 0008, 0020
Semivox	0045, 0209
Semp.....	0045
Sentra	0072, 0278, 0020
Setron	0072
Sharp	0037, 0048, 0047, 0032, 0000, 0209, 0569, 0062, 0065, 0363, 0807, 0848, 1048, 1285, 1400, 1815
Shinco	0000
Shintom.....	0039, 0240, 0000, 0104, 0072, 0208
Shivaki.....	0037
Shogun	0240, 0051
Shorai	0088

VCR

Downloaded From TheatreSystem-Manual.com Manuals

VCR

Siemens	0037, 0081, 0104, 0320, 0046, 0054, 0347, 0510
Siera	0081
Signature	0060, 0035, 0037, 0048, 0000, 0149, 0046, 0065, 0066, 0479
Silva	0037
Silver	0278
SilverCrest	0642
Singer	0037, 0240, 0045, 0072, 0348, 0271
Sinudyne	0081, 0209, 0352
Smaragd	0348
Solavox	0020, 0034
Sonic Blue	0614, 0616, 0643, 1137
Sonneclair	0072
Sonographe	0046
Sonolor	0048, 0046, 0062
Sontec	0037, 0278
Sonwa	0642
Sony	0035, 0048, 0047, 0032, 0033, 0000, 0067, 1972, 1636, 1448, 1447, 1297, 1296, 1295, 1232, 1032, 0640, 0639, 0636, 0586, 0046, 0034, 0011
Soundmaster	0000
Soundwave	0037, 0209, 0348
Ssangyong	0072
Stack 9	1972
Standard	0278
Stern	0278
Strong	0271
STS	0042, 0105
Sunkai	0209, 0278, 0348, 0295
Sunstar	0000
Suntronic	0000
Sunwood	0072
Supra	0037, 0278, 0348
Susumu	0037
SV2000	0000, 0072
SVA	0000
Sylvania	0035, 0081, 0000, 0043, 0110, 0593, 1593, 1781
Symphonic	0240, 0000, 0002, 0593, 1593
Systemax	1972
T+A	0162
Tagar Systems	1972
Taisho	0209, 0088
Tandberg	0278
Tandy	0000, 0104
Tashiko	0037, 0048, 0081, 0240, 0000
Tatung	0048, 0081, 0045, 0000, 0067, 0043, 0209, 0041, 0348, 0352, 0008, 0053, 0366
Tchibo	0348
TCM	0348
Teac	0037, 0000, 0067, 0041, 0072, 0278, 0307, 0642, 0526, 0593, 0844, 1593
Tec	0072, 0020
Tech Line	0072
Technics	0035, 0162, 0037, 0081, 0000, 0246, 1162
TechniSat	0348
Technosonic	0352
Teco	0035, 0037, 0048, 0041, 0038
Tedelex	0037, 0209, 0348, 0642
Teknika	0035, 0037, 0000
Teleavia	0041
Telecorder	0240
Telefunken	0209, 0041, 0278, 0642, 0320, 0384, 0208, 0593
Telenet	1784
Telestar	0037
Teletech	0000, 0072, 0278
Tempest	0020
Tenosal	0072
Tensai	0037, 0000, 0072, 0278
Tevion	0209, 0348, 0642, 0479
Texet	0278, 0020
Thomas	0000, 0002
Thomson	0060, 0067, 0041, 0278, 0320, 0384, 0202
Thorn	0037, 0104, 0041, 0320, 0036, 0443
Tisonic	0278
Tivo	0618, 0636, 0739, 1337, 1996
TMK	0240, 0000, 0036, 0208
TNIX	0037
Tocom	0240
Tokai	0037, 0104, 0041, 0072
Topfield	1959, 2045
Topline	0348
Toshiba	0081, 0240, 0045, 0000, 0042, 0067, 0043, 0209, 0041, 0384, 0352, 0432, 1384, 1386, 1972, 1325, 1323, 1996, 1290, 1289, 1145, 1008, 0845, 0828, 0742, 0544, 0366, 0212, 0210, 0066, 0062, 0054, 0008
Tosonic	0278
Totevision	0037, 0240
Touch	1972
Towada	0072
Toyoda	0278
Tradex	0081
Trakton	0020
Triad	0278
Triumph	0208
Trix	0037
Uher	0240
Ultra	0045, 0278, 0020
Ultravox	0278
Unitech	0240, 0051
United	0348, 0742, 1593
Universum	0037, 0081, 0240, 0000, 0104, 0209, 0348, 1137
Vector	0045
Vector Research	0184, 0038
Vextra	0072
Victor	0067, 0041, 0384, 0008, 0370, 1283, 1299
Video Concepts	0045, 0061, 0210, 0242
Video Pro	0020
Video Technic	0000
Video Track	0443
Videomagic	0037
VideoPro	0020
Videosonic	0240, 0000, 0072
Viewsonic	1972
Villain	0000
Voodoo	1972

Downloaded From TheatreSystem-Manual.com Manuals

Wards	0060, 0035, 0037, 0048, 0039, 0047, 0081, 0033, 0240, 0045, 0000, 0042, 0043, 0041, 0072, 0038, 0149, 0046, 0058, 0018, 0062, 0065, 0011, 0212, 0479, 0760
Watson	0081, 0642, 0352
Weltblick	0037
Wharfedale	0642, 0593, 0615
White Westinghs	0000, 0209, 0072, 0278, 0479
World	0209, 0002, 0348, 0479
XR-1000	0035, 0240, 0000, 0072, 0208
Yamaha	0041, 0038
Yamishi	0072, 0278
Yokan	0072
Yoko	0037, 0240, 0072, 0020
Yoshita	0072
Zenith	0037, 0039, 0033, 0000, 0209, 0041, 0278, 0011, 0034, 0479, 1137, 1139, 1479
ZT Group	1972
ZX	0209, 0348, 0352

A-ACC

Accurian	2502
Altec Lansing	2500, 2501
Apple	2503, 2505
DLO	2504, 2509
Griffin	2508
iPort	2506, 2507
NaviPod	2505
Sonance	2506, 2507
TEN Technology	2505

V-ACC

ABS	1272
Accurian	1653
Alienware	1272
Amino	1481
Axonix	1447
Buffalo	1739
CyberPower	1272
D-Link	1554, 1731
Dgtec	1363
Epson	1563, 1650
Gateway	1272
Hewlett Packard	1272, 1267
Howard Comps	1272
HP	1272, 1267
Hush	1272
iBUYPOWER	1272
Keyspan	1344
KoolConnect	1481
LG	1415
Linksys	1272, 1365
Macro Image Tech.	1383
Media Center PC	1272
Microsoft	1272, 1805, 2049
Mind	1272
Motorola	1363
MyHD	1383
Niveus Media	1272
Northgate	1272
Packard Bell	1272
Panasonic	1120
Philips	1218
Pinnacle Systems	1447
Pioneer	1010
ReQuest	1245
Ricavision	1272
Roku	1486
Samsung	1190, 1490
Sensory Science	1126
Sharp	1010
Sony	1272, 1324, 1364
Stack 9	1272
SureWest	1481
Sylvania	1563
Systemax	1272
Tagar Systems	1272
Toshiba	1272
Touch	1272
Viewsonic	1272, 1329
Vizio	1126
Voodoo	1272
Xbox	1805, 2049
Zinwell	1363
ZT Group	1272

R-ACC

Bose	1629

Downloaded From TheatreSystem-Manual.com Manuals

Downloaded From TheatreSystem-Manual.com Manuals

Downloaded From TheatreSystem-Manual.com Manuals

Downloaded From TheatreSystem-Manual.com Manuals

BOSE®

Better sound through research®

©2008 Bose Corporation, The Mountain,
Framingham, MA 01701-9168 USA
AM312515 Rev.01